

List of Compatible Models		
Name	Model	Code
Sony α99	SLT-A99V (with GPS), SLT-A99 (without GPS), (Hasselblad HV)	CX87500
Sony α900	DSLR-A900	CX85100, CX62500
Sony α850	DSLR-A850	CX86700
Sony α77 II	ILCA-77M2	
Sony α77	SLT-A77V (with GPS), SLT-A77 (without GPS)	CX87000, CX87010
Sony α700	DSLR-A700 (only US-model with grip-sensor)	CX62300, CX62320
Sony α65	SLT-A65V (with GPS), SLT-A65 (without GPS)	CX86800, CX86810
Sony α580	DSLR-A580	CX86600, CX86610
Sony α58	SLT-A58	CX87600
Sony α57	SLT-A57	CX87400
Sony α560	DSLR-A560	CX86500
Sony α550	DSLR-A550	CX85800
Sony α55	SLT-A55V (with GPS), SLT-A55 (without GPS)	CX86400, CX86410
Sony α500	DSLR-A500	CX85700
Sony α450	DSLR-A450	CX85900
Sony α390	DSLR-A390	CX86200
Sony α380	DSLR-A380	CX85600
Sony α37	SLT-A37	CX87100
Sony α350	DSLR-A350, DSLR-A350K/N (champagne gold-colored set)	CX62900
Sony α35	SLT-A35	CX86900, CX86910
Sony α330	DSLR-A330, DSLR-A330L/T (copper brown-colored set)	CX85200
Sony α33	SLT-A33	CX86300, CX86310, CX86311, CX86320

Sony α300	DSLR-A300, DSLR-A300K/N (champagne gold-colored set)	CX62800
Sony α290	DSLR-A290	CX86100
Sony α230	DSLR-A230	CX85500
Sony α200	DSLR-A200	CX62700
Sony α100	DSLR-A100, DSLR-A100/S (silver-colored body)	CX62100, CX62110, CX62120