


• Imagine  
Isteam

---

# ISTEAM USER MANUAL



BRING NEW LIFE TO CLOTHING.



## DANGER

Close parent supervision is necessary for any appliance that is used near children. Do not leave your isteam unattended while connected.



It is possible that you might burn yourself while using your isteam. Use carefully and never turn your isteam upside down because hot water may pour from the water deposit.

## WARNING

To reduce the risk of contact with hot water coming from steam vents, check the water level and the indicator light on your isteam before each use. Use this appliance for its intended use only.

To reduce the risk of electric shock, do not immerse your isteam in water or other liquids.

Never pull out the cord to disconnect from the outlet, instead, grasp the plug and pull to disconnect completely before putting it away. Place the cord loosely when storing.

Always keep your isteam disconnected from any electrical outlet when filling it with water, when emptying it, and when it is not in use.

Do not operate your isteam when the cord is damaged, or if the appliance has been dropped or damaged.

To reduce the risk of electric shock, do not disassemble or attempt to repair your isteam if damaged. Return it to the Service Center for repair. An incorrect reassembly or repair could result into a fire, electric shock, or injury when the appliance is used.

## WARNING

Never drop or insert any object into the steam vents of the nozzle.

Do not use the isteam outdoors, operate it where aerosol products are being used or where oxygen is being manipulated.

The surface of your isteam may get hot when it will be in use. Always use a handle to avoid burning your skin.

Do not place the steam nozzle directly on any surface or on the appliance power cord while it is not or plugged in.

Unplug your isteam before filling or emptying the water tank. Never fill water past the maximum level.

To reduce the risk of a circuit overload, do not operate another high-voltage appliance on the same circuit.

Do not use an io extension cord to operate the appliance. If an extension cord is absolutely necessary, then a 15 amp rated extension cord should be used. Bare in mind that extension cords with less amperage may overheat.

Be careful when arranging the cord so it cannot be pulled or tripped over.

Thank you for purchasing your isteam, the perfect tool to keep your wardrobe and household fabrics fresh and wrinkle-free. Use it daily to easily and quickly revive all your clothing.

---

## FEATURES

**We've designed your isteam to give you a portable yet powerful steaming experience. Some of the features that you will enjoy with this product include:**

- New nozzle design that distributes steam powerfully and consistently to remove stubborn wrinkles.
- Compact design that makes the isteam easily to store and travel with Safe to use on all types of fabric.
- Heats quickly to emit wrinkle-busting steam.
- Includes an automatic shut-off feature for safety protection when the unit gets too hot or too low on water level.
- High-captivity, easy fill water tank that lasts for 10 minutes of continuous steaming.
- 2 Year Warranty-Your satisfaction is guaranteed!

## HOW TO OPERATE YOUR ISTEAM

1. Unscrew the nozzle head, fill the tank with cold water up to the desired level, never exceed the maximum level. When finishing, lock the head back on.
2. Turn ON/OFF switch to ON position. The switch light indicates the steamer is on. The steamer will emit steam from a nozzle in 1 minute.
3. When the unit runs out of the water, it will reset itself automatically to ensure your safety while leaving the indicator light ON. If you wish to continue your steaming session, turn ON/OFF switch to the OFF position, refill the water tank by following step 1 again, then turn ON/OFF switch to ON position.
4. When finished, place the ON/OFF switch in the OFF position and remove the plug carefully from the outlet.

**NOTE: Never turn the unit upside down. Your steamer should never be tilted past a 45-degree angle, especially when the unit is ON. For perfect use - please use a hanger to hang your clothes while steaming.**

---

## CLEANING YOUR ISTEAM

1. Unscrew the head and allow your isteam to cool for at least 10 minutes.
2. Empty any water remain from the water tank and allow it to air dry before replacing the head and setting the tank back in the unit.

## STORING YOUR ISTEAM

1. Store it in a cool dry place.
2. **DO NOT wrap the power cord around the unit, place it loosely.**

NOTE: Water containing mineral levels will vary depending on the place where you live in. To ensure the continuous operation of the steamer, never store it without cleaning and removing excess water from the water container or tank.

If you fill your isteam with tap water, you may experience mineral build-up due to the high mineral content in the water supply in many cities. Mineral residue inside your isteam's internal heater may cause intermittent steaming or, in severe cases no steaming at all.

To avoid the problem, only use de-mineralized or distilled water in your isteam. If you are unable to use de-mineralized or distilled water, we recommend you to follow the cleaning procedure below at least once a month to help avoid mineral build-up.

1. Turn the unit off and unplug the power cord.
2. Prepare a mixture of 50% vinegar and 50% water, in most cases 1 cup of this mixture will be enough.
3. Slowly pour the water-vinegar mixture into the water. Pour it out three minutes later.
4. If the procedure above does not return the unit to a normal operation, the unit may need to be checked by the product supplier.

**If your isteam is not operating properly, please check if it is related to any of the following problems or conditions. If you are still unable to detect and solve the problem, please contact us for a replacement.**

---

### Your isteam fails to heat

**Your isteam should heat within two minutes. If after two minutes your isteam is still cool, check the following:**

1. Make sure the steamer is plugged into an electrical outlet.
2. Fill the water tank. The automatic shut-off feature prevents your isteam from heating when the water level is low.

### Your isteam is not emitting steam

If your isteam is not emitting steam, the water level is too low. Turn the ON/OFF switch off and refill.

### Water is spraying from the nozzle

If your isteam is spraying water from the nozzle, the water tank is too full. Pour some water out until the water level is under the maximum level.

### Nozzle gurgles

If the nozzle of your isteam makes a gurgling sound there is condensation around the nozzle. This is normal. Hold the steamer vertically and shake the body to allow water to drain back into the tank.

### Steam flows intermittently

If your isteam is not emitting a continuous flow of steam, sediment build-up is likely to be the problem. Follow the procedure for removing mineral build up of this User Manual explained above.