

# Trouble Shooting Steps:

- Place the appliance on the charging base.
- Plug in the charger.
- Leave the appliance to charge. If the appliance detects a damaged battery, the charging indicator will flash at a fast rate when the appliance is on the charger base. Proceed as follows:
- Take the appliance and the charger to be tested at an authorized service facility.

Note: It may take as long as 60 minutes to determine that the battery is defective. If the battery is too hot or too cold, the LED will alternately blink, fast and slow, one flash at each speed and repeat.