

Secure Device Setup

1. Download the app.

Visit the App Store, Google Play, or <http://canary.is/app> to download the free Canary app on your smartphone.

2. Launch the app.

Open the app on your Android or iOS device.

3. Follow in-app instructions.

The Canary app will walk you through creating an account and setting up your device.

Placement

Pick a place with a strong Wi-Fi signal.

If you think you've found a suitable place, try streaming Watch Live from your Canary Flex device there. If it plays without interruption, you've found a good place for your device to live.

Place Canary Flex outside to record outdoor activity. Canary Flex will not detect motion through a window while operating on battery power.

Plugging in Canary Flex outdoors.

Use wire-free at any time. You can plug your device into a weatherproof, covered outlet if you see a green dot on the bottom of the power adapter.