




ARCADE JOYSTICK QANBA TITAN



Instruction Manual

Model: B1

Features




- | | |
|-----------------------------|--|
| 1. USB cord and compartment | 10. TURBO button |
| 2. Sanwa lever | 11. CREATE button (SHARE button for PS4™ consoles) |
| 3. Sanwa 30mm buttons | 12. MUTE button |
| 4. Touch pad | 13. R3 button |
| 5. Mini buttons | 14. MODE switch |
| 6. 3.5mm headphone jack | 15. COMPATIBILITY switch |
| 7. OPTIONS button | 16. LOCK/UNLOCK switch |
| 8. PS button | 17. Qanba lever access hole |
| 9. L3 button | |

~1~

English

Operating Instructions

1. Turn on your PlayStation®4 console or PlayStation®5 console.
2. Use the COMPATIBILITY switch (15) to select the appropriate PS5™ setting or PS4™ setting.



3. Ensure the LOCK/UNLOCK switch (16) is set to unlocked.
4. Plug your joystick into your console.
5. Press the PS button (8) to initialize the joystick.
6. Press and hold the PS button (8) if you would like to change the player assignment.

* PC compatibility not tested nor endorsed by Sony Interactive Entertainment.

LOCK/UNLOCK Switch (Tournament Mode)

- To enable tournament mode, slide the LOCK/UNLOCK switch (16) to the locked setting.
- In a competitive setting, players may choose to disable these buttons:
 - CREATE button (SHARE button for PS4™ consoles) (11)
 - TURBO button (10)
 - PS button (8)
 - OPTIONS button (7)




~2~

English


MODE Switch

- The Sanwa lever (2) can be toggled between three unique control modes:
 - Directional Pad (DP)
 - Left Analog Stick (LS)
 - Right Analog Stick (RS)
- Slide the MODE switch (14) to toggle between the three unique control modes.



MUTE Button

- When the 3.5mm headphone jack (6) is not used, the MUTE button (12) has no function
- When headphones are connected to the 3.5mm headphone jack (6), the headphone's microphone can be toggled between two unique control modes:
 - Microphone active (default setting) - MUTE button LED off
 - Microphone off - MUTE button LED on
- Press the MUTE button (12) to cycle between the two unique control modes




~3~

English

TURBO Button

- Each of the eight Sanwa buttons (3) can be toggled between three unique turbo modes:
 - Turbo Off – LED off (default)
 - Push for Turbo – LED flashing red when button pressed
 - Auto Turbo – LED always flashing
- Press the TURBO button (10) and the unique Sanwa button (3) at the same time then release to cycle between the three unique turbo modes.



Qanba Lever Access Hole

- The level access hole provides access to the Qanba lever screw connected to the ball top.
- Turn the Qanba lever access hole (17) cover counter-clockwise and remove to gain access.
- Replace the Qanba lever access hole (17) cover and turn clockwise to close the access hole.



Specifications

Product Name	Qanba Titan Arcade Joystick
Model	B1
Buttons	8 x Sanwa Buttons
Joystick	Sanwa Lever
Dimensions	384mm x 221mm x 115mm / 15.1in x 8.7in x 4.56in
Weight	2.25kg / 5.0lb
Wired USB Cable Length	2.7m / 9ft
Product Color	Black

Compliance Information

This product complies with the following compliance and safety testing:

- USB:2.0 compliant.
- FCC: This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

~4~

English

Warnings and Safety

- Carefully read the instruction manual.
- Do not clean joystick with alcohol or fluids. Use a dry cloth.
- Do not disassemble joystick.
- Unplug the joystick and wrap the USB cord when not in use to prevent tripping hazards.
- Keep joystick in a cool dry place away from liquids, smoke, and chemicals.
- Do not keep joystick in hot climates such as the trunk of your car in summer heat for prolonged periods of time.
- Do not stack other items on top of joystick.
- Retain the instruction manual for future reference.
- Commercial use of this product is prohibited.
- Joystick design and specifications are subject to change without notice.
- Product is not suitable for children under 12 years of age.
- Qanba USA, LLC will repair or replace product at its discretion 12 months from purchase date.

Customer support

- Telephone: (888)525-8783
- Email: usa@qanba.com

~6~

English

~5~

English

"PS", "PlayStation", "PS5", and "PS4" are registered trademarks or trademarks of Sony Interactive Entertainment Inc. All other trademarks are the property of their respective owners. Manufactured and distributed under license from Sony Interactive Entertainment.

QANBA and QANBA are registered trademarks of Shenzhen Qanba Technology Development Co., Ltd and are used under license.

Qanba USA, LLC
1445 S Tippecanoe Ave
Suite 100
San Bernardino, CA. 92408
United States
www.qanbausa.com

