

Before starting to set up a Link, please confirm the following:

1. Your PC meets the recommended specs.
2. Your Oculus software is up to date on both your PC and headset.

Steps to use your Meta Quest or Quest 2 with Link

1. **Download** the Oculus app from Oculus.com and **install** the app on your PC.
2. **Follow** the instructions to set up your profile and **Select** Quest 2 on the app.
3. **Turn on** your Quest 2 headset.
4. **Plug** the USB-C end into your headset and the USB-A end into a USB 3.0 port on your compatible gaming PC.
5. **Strap** your link cable to your headset before wearing your headset.
6. **Put on** your headset to **complete** the in-headset instructions.
 - A message displays in VR prompting you to **Allow access to data**. Select **Deny**. If you mistakenly 'Allow' the prompt, you must unplug your USB cable from the headset and plug it back in.
 - When prompted to **Enable Oculus Link**, select **Enable** to begin remote rendering using Oculus Link.
7. **Enjoy** the PC VR games on Oculus Rift or SteamVR.

Here is a video tutorial from Oculus official:

<https://www.youtube.com/watch?v=IQrPiTIsU9I>

If you're unable to enable Oculus Link:

- If you don't see **Add Meta Quest** as the device on the PC software: log out of the PC software and log back in.
- If you don't see the **Enable Link** pop-up on the PC software: log out of the PC software and log back in.
- If you don't see the **Enable Link** option under Settings on your headset: completely power off the headset and restart.

If it still fails, please look up **Troubleshooting PDF** or **contact WARRKY** for tech support.

-Amazon Buyer/Seller message:

1. Go to **Your Orders**.
2. Find your order in the list.
3. Select **Problem with order**.

Choose your topic from list displayed.

4. Select **Contact seller**.

-WARRKY Support Email:

support@warrky.com

You will have quick and responsible tech support within 18hrs.