

Acepen906 Drawing Tablet FAQ

How to set the pressure of the pen tablet in PS?

When using the background color eraser tool, the tablet is applied: If you are using a pressure-sensitive tablet, please select the options in the "Size" and "Tolerance" menus to change the size and content of the background eraser in the stroke line. Poor. Select "Pen Pressure" to change according to the pressure of the pen. Select "Pen Wheel" to change according to the position of the pen thumb wheel. Select "Off" to not change the size and tolerance.

When using the repair brush tool, the tablet is applied: If you are using a pressure-sensitive tablet, select the option from the "Size" menu to change the size of the repair brush during the stroke. Select "Pen Pressure" to change the size of the repair brush according to the pen pressure And change. Select "Light pen wheel" to change according to the position of the pen thumb wheel. Select "Off" to not change the size.

When drawing with the magnetic pen option, the tablet application: If you are using a tablet, please select or deselect "pen pressure". When this option is selected, the increase in pen pressure will cause the width to decrease. Set lasso, polygon When using the lasso and magnetic lasso tool options, the tablet is applied: If you are using a tablet, select or deselect the "pen pressure" option. If this option is selected, increasing the pen pressure will cause the edge width to decrease.

What is the difference between a pen tablet, a pen display, and a touch monitor?

The digital tablet, also called the hand-drawn tablet, is an external handwriting input device, connected to a computer, and used a special pen to write and draw on the tablet to achieve the purpose of presentation on computer software. Unlike ordinary writing boards, professional hand-drawn tablets have pressure Sensation level, in short, can recognize the size of your hand force, so as to present different effects such as lightness, depth, and thickness on the computer. The pen tablet is generally used as a professional drawing and design tool. The pen tablet does not have the display imaging function, so the disadvantage is that the hand and the eye are not integrated. You need to stare at the computer monitor. People who are new to contact, even if they have strong drawing skills, need some practice. adapt.

The digital screen, also called the hand-painted screen, is also an external writing and painting hardware. It also needs to be connected to a computer. On the basis of the hand-painted board, it realizes the display imaging function. You can use the product's matching brush to directly write, draw and design on the digital screen. , (Some products also support ten-finger touch function, which makes it easy to use fingers to

select software tools and other operations when creating. It sounds very convenient, but I still like keyboard shortcuts.) With pressure-sensitive function, hand and eye are integrated, compared to hand-painted The board is easier to control. The disadvantage is that there is a certain parallax (after all, the screen has a thickness) and the price is higher. The price of a good hand-painted screen is more than 7000, and the high-end hand-painted screen will not exceed 30,000 yuan. Low-priced domestic hand-painted screens have various shortcomings and deficiencies, but the cost performance can be measured as an entry-level purchase.

In addition, there is now a drawing tablet, which is a combination of a personal computer and a hand-painted screen. It can be used to paint or design anywhere without connecting to a computer. It is very convenient and more expensive.

As for the touch display... it is simply a display that supports finger touch, which is equivalent to a mobile phone screen.

Is it necessary to use a pen tablet to edit photos with Photoshop?

If you are a daily household, it is not necessary. If you are a professional and need to involve fine-tuning or a lot of picture finishing, then the digital tablet is very necessary! But it is not necessary, that is to say, without a tablet, the picture can be repaired, but with a tablet, you can reduce your work pressure to a greater extent and improve the fineness of your retouching. What are the advantages of the tablet? The biggest advantage of using the tablet to retouch the image is that it is more flexible and finer in the control of the brush, and more delicate when rubbing the mask. As a result, while improving work efficiency, it also improves the quality of work. It has the best of both worlds.

Therefore, professional retouchers basically use the digital tablet to retouch pictures. You try to use an ordinary mouse to refine dozens of photos a day. It's true that your hands will be abolished, but using a tablet does not say how much efficiency is improved, at least the mouse hands are much better, right? Before there was a pen tablet, a professional retoucher was gnashing his teeth when talking about a mouse hand. So if you are a professional retoucher and need a lot of long-term retouching, don't hesitate to come with a tablet. You may be uncomfortable at first, but believe me, after you get started, you will immediately put your mouse into the cold palace.

What should I do if I can't write with a digital pen? (Windows)

When using the tablet, some friends will encounter the situation that the pen cannot write characters. In this situation, you can check the following items first to eliminate whether it is a product hardware problem.

1. Check whether there are system and software incompatibility problems between the tablet and the computer:

Windows system: only supports Win 7/8/10 or above;

Office software: WPS and Office 2010 versions below are not supported, and DingTalk is not supported.

2. Check whether the driver of other brands of tablet is installed on the computer. If there is, you need to uninstall it, otherwise it will be incompatible. (Other types of tablet drivers also need to be uninstalled)

Uninstall operation steps: Click [Start]-[Settings]-[Applications], find other tablet drivers, and uninstall

3. When the computer system and software are compatible, check whether the driver is installed on the tablet again. If the driver has been installed before, but the pen still has problems, uninstall the driver at this time.

Uninstall operation steps: Click [Start]-[Settings]-[Apps]-[DigitizerPanel]-[Uninstall]

4. After uninstalling the driver, try to write on the board with the pen at this time to see if the pen responds (that is, the pen can move normally like a mouse, and the light on the board flashes normally), if it responds, just reinstall the driver. .

Driver installation steps:

Open the Acepen official website-click [support]-change the language to [Simplified Chinese] in the upper right corner-click [driver download]-find the [driver] of Windows and download it.

5. If the pen still fails to respond (it cannot move normally on the computer screen and cannot write), the hardware is defective, please contact the official after-sales customer service to solve it.

How to use the graphic tablet on a Windows computer?

Tablet-Windows computer usage tutorial: For those who just started with a tablet but don't know how to use the product in Windows, please see here to teach you how to install the driver and set up the program~

(Note: The tablet is currently only compatible with Windows 7, 8, 10 or above)

1. Use the USB Type-C cable provided with the product to connect the tablet to the computer.

2. Check whether other brands of tablet drivers are installed on the computer (take

Wacom as an example), and uninstall them, otherwise it will be incompatible. (If there is a driver for other models of digital tablets, you also need to uninstall it)

Specific uninstallation steps: Click [Start]-[Settings]-[Apps]-[Wacom Tablet]-[Uninstall]

3. Open the Acepen official website, download the latest driver, and install it.

Official website (www.ace-pen.com)-click [support]-change the language to [Simplified Chinese] in the upper right corner-click [driver download]-find Windows [driver], download and install.

4. After the installation is complete, restart the computer to start using it. Open **【Digitizerpanel】** , you can set the shortcut keys of the tablet.

How to use the pen tablet on an Apple computer?

Tablet-Apple Computer Tutorial: For those who just started with the tablet but don't know how to use the product in macOS, please see here to teach you how to install the driver and set up the program~

1. Unpack and connect the tablet to the computer with a USB Micro data cable.
2. Before installing the driver, you need to check if there are other tablet drivers on the computer. No matter what the driver is, you need to uninstall it first, otherwise it will be incompatible (including other types of tablet drivers, also need to be uninstalled)

Specific uninstallation steps: Open the Apple computer, click [Visit], and then click [Applications], find the driver that needs to be uninstalled, and uninstall it.

3. Uninstall the other drivers and start to install the drivers at this time.

Specific installation steps: Open the official website of Acepen (www.ace-pen.com)-click [support]-change the language to [Simplified Chinese] in the upper right corner-click [driver download]-find the [driver] of MAC, download.

4. If you are prompted during the installation process that the driver cannot be installed, you need to set the "Security and Privacy" for the computer at this time. (If there is no prompt, please ignore this step)

Specific operation steps: Return to the main computer interface, open [System Preferences], click [Security and Privacy], then click [General], click [Open anyway], and then click [Open], and follow the steps to complete the installation.

5. After the driver installation is complete, the computer system is a small partner of Mac OSX: 10.11-10.13, and the product can be used.

The computer system is a small partner of Mac OSX: 10.14 and 10.15, and the last step [drive related settings] is required before the A610s tablet can be used.

6. Mac OSX: 10.15 driver setting steps:

1) Click [Privacy] in [Security and Privacy], click to unlock in the lower left corner, find [Accessibility], search and add "pentablet"

2) Find [input monitoring], search for and add "pentablet", click lock in the lower left corner after adding it, restart the computer to use it.

7. Mac OSX: The 10.14 driver does not need to set the [input monitoring] function, the other is the same as 10.15, just follow step six.

What to do if the digital pen draws a straight line in PS In the case that the lines are straight lines no?

In the case that the lines are straight lines no matter how the digital pen is drawn in PS, you can follow the steps below~

(This experience is only for friends with Win10 system, PS CC2017 and above)

1. Take PS CC2017 as an example:

Open [My Computer], enter "%appdata%\Adobe" in the Explorer (My Computer), and then press Enter.

2. Locate and open the Adobe Photoshop CC 2017 folder.

3. Locate and open the Adobe Photoshop CC 2017 Settings folder.

4. Find the [PSUserConfig] text file, right-click and select "Delete", then restart the PS, try to see if the line has changed, if it still does not resolve, contact after-sales service

Precautions

Win7, 8 system cannot be modified temporarily, you need to upgrade to win10 system

first

PS version requires PS CC2017 and above.

How does Office in Windows computers support handwriting?

For those who bought a tablet but can't write in Office, see here. This tutorial is for Windows.

1. This article takes PPT as an example. Open PowerPoint on a Windows computer, click "Review" in the menu bar, and then click "Enable Ink Writing" to start using the writing function.
2. If the "ink writing" function is not displayed in the "review", or the display is gray and cannot be clicked, you need to set it up again.
3. Click "File" in the window to enter the navigation window, and then click the "Options" button below.
4. Click "Customize the Ribbon" in the powerpoint options, and then select "Command not in the Ribbon" from the following location, and find "Start Inking"
5. Click "Add", and then follow the pop-up window requirements to "New Group".
6. Click "Ink", then click "Hide Ink Menu", and click "New Group" below.
7. After creating a new group, add "Start Inking" on the left to the group.
8. Click "OK", and you can see the "Start Inking" function in the PPT "Review" menu bar. Click this function to start writing. (The steps for Word and Excel are the same)

Note: Office must be version 2010 and above.

What should I do if I receive a prompt no device after the tablet is connected to computers?

If your tablet data cable is plugged into the computer, but the computer prompts "Cannot find tablet" or "No device", you can follow the steps below to check carefully.

In the case of the prompt "device not connected" after clicking the driver, please check carefully according to the following steps:

1. Make sure your data cable can be used for other devices
2. After connecting, if you continue to receive the error message of the tablet, it means that the currently installed driver may not be the correct driver for your tablet
3. Make sure that the data cable of the tablet is directly connected to the computer. Using a USB docking station may cause this situation

Please follow the steps below to repair:

1. Re-insert the device;
2. Replace the USB port connection of the computer/laptop;
3. If you use a Type-C adapter, please make sure that the adapter can be used with other devices;
4. Uninstall the driver and restart the computer, connect the tablet and install the driver.

What should I do if the digital pen can only draw straight lines without pressure sensitivity in PS?

If the line drawn by the digital pen in the PS does not change in weight or thickness (the pen has no pressure sensitivity), no matter how you draw it is a straight line, you can follow the steps below~

1. Take PS CC2017 as an example:

Open [My Computer], enter "%appdata%\Adobe" in the Explorer (My Computer), and then press Enter.

2. Locate and open the Adobe Photoshop CC 2017 folder.
3. Locate and open the Adobe Photoshop CC 2017 Settings folder.
4. Find and open the PSUserConfig text.
5. After opening, you will see two lines of English starting with "# Use".

If the value at the end is 0, change it to 1, save and exit to restart PS.

6. If after the above steps are set, the Parblo digital pen in the PS still has no pressure sensitivity, delete the [PSUserConfig.txt] text file, and then restart the PS.

What should I do if the digital pen has no pressure sensitivity in PS?

When the line drawn by the digital pen in the PS does not change in weight or thickness (the pen has no pressure sensitivity), it may be caused by some wrong settings in Photoshop and driver problems. You can follow the steps below~

(This experience is only for friends with Win10 system, PS CC2017 and above)

1. Check whether the pressure sensitive setting is turned on in PS.
2. After opening, first select the brush tool, and then click a "brush icon" on the menu bar to switch to the [brush settings] panel
3. In the [Brush Settings] panel, check "Shape Dynamic". And in the drop-down menu in the "Control" section on the right, select "Pen Pressure"
4. If an exclamation mark appears in front of "Control", you need to use a digital pen to operate it. In the drop-down menu in the "Control" section on the right, first use the digital pen to select "Off", and then click "Pen Pressure".
5. If the digital pen still has no pressure sensitivity after the above steps, you need to modify the PS related folders.

Take PS CC2017 as an example:

Open [My Computer], enter "%appdata%\Adobe" in the Explorer (My Computer), and then press Enter.

6. Locate and open the Adobe Photoshop CC 2017 folder.
7. Locate and open the Adobe Photoshop CC 2017 Settings folder.
8. Locate and open the PSUserConfig text.

How does Microsoft Office in macOS support handwriting?

For those who bought a tablet but don't know how to write in Office, look here. This article is for macOS.

(PS: Office version requires 2019 and above)

Open Word, Excel or PowerPoint in macOS, first check if there is "Drawing" option in the menu bar. If not, this office version does not support handwriting function, please update to version 2019 or later.

If there is a "Drawing" option in the menu bar, click on "Drawing" and then select the pen.

Can I draw sketches with the pen tablet?

We mostly use pencils and charcoal for training on paper sketches, with the aid of smear tools. There are also upper-grip, upper-grip pinky support, triangle, and triangle pinky support. The wiring methods are even more varied. These are all techniques developed from the limitations of the natural properties of traditional painting materials, and the board painting combines all these into a "pave".

There is really a difference between a sketch on paper and a sketch drawn on a board. How should the board sketch be drawn?

1. In the process of drawing, try not to use a soft brush from beginning to end, use less smearing and blending brushes, and best use hard-edged pens to overdo it with bare hands. At the beginning, I feel overly uncomfortable. It is nothing more than being unskilled. After getting used to the hard-edged pen, I can also have a very comfortable excess and retain the handwriting feeling, and it will not be so greasy.
2. The brush should be as small as possible and use a grainy brush. We know that the texture part of the picture mostly appears at the junction of light and dark. Use particles and texture in a small area, and use the right position to make it more rhythmic.
3. When the hard transition is clearly stuck, the picture feels "fuzzy" and is divided, making it a soft and hard sense of virtuality and reality..

How to change the refill of the hand-painted board?

What should I do if the pen on the tablet is broken? The tablet is used to connect the external devices of the computer for hand-painting. The pen core of the pen tablet also needs to be replaced frequently, and the replacement of the pen core of the pen tablet also requires skill.

What we need to use is the pen picker box, pen picker, refill and fine art pen.

Note that the way to replace the refill of the pressure sensitive art pen and the pressure sensitive rechargeable pen is the same. First of all, we need to take out the pen core that needs to be replaced. We need to use the pen taker, as shown in the figure, the pen taker is in the center of the pen box.

As shown in the picture, this small iron ring is the pen extractor. There is a small hole inside, which is the place where the pen core is aligned. With two thumbs, the pen-removing device can be closed and the pen-removing operation can be performed.

Then you can take the pen. Align the small hole with the pen core, forcefully narrow the opening and clamp the pen core, then the pen core can be pulled out slowly

Then it is time to replace the refill. In the same way, use a pen taker to take out the pen core from the pen take-out box.

Then gently insert the other end of the refill into the pressure sensitive pen until the refill reaches the proper position. Loosen the pen extractor and the refill replacement is complete.

After the replacement is completed, put the pen core and the pen taker into the pen take box, and all the procedures are completed.

What to do if the pen tablet driver is not running?

The little friends of the tablet often encounter that the tablet has no pressure sensitivity, and every time it is restarted, it will show that the tablet driver is not running, and then it cannot be used. Uninstall the program of the tablet again, and then use the CD. It can be used after installing it once, but as long as the computer is turned off and on again, it cannot be used again. What is going on? The solution is here! This is a driver bug, and it can be done in the following 2 steps!

The first step: Open the control panel-management tools-services, find: "pen tablet service", close it once, and then open it again. Open the desktop and refresh it again, it's fine. If it still doesn't work, go to the second step!

Step 2: If the first step is useless, unplug the line of the tablet and repeat the above steps several times. This method is 100% effective. There is no need to repeatedly load and unload the driver like many people do, just one solution! I feel that many people don't know this good method!

After solving the board problem, don't let the board be left there, or it will get dusty, so draw more.

Why doesn't the hand shake when holding the pen tablet? How to draw nice lines?

Why doesn't the hand shake when holding the pen tablet? How to draw nice lines? Many people start from the line when they learn board drawing. The control of the line has always been the first big problem encountered by beginners. When a beginner can well control the thickness, virtual reality, line direction, and degree of curvature of the line, the beginner's self-confidence will rise and he will truly step into the big "pit" of painting.

Having said that, is the control of lines just for blind drawing? Obviously not. Then, there are certain methods for the board drawing, which will take you to avoid shaking the pen into an earthworm.

1. Misunderstandings about holding a pen

Copying is a good way to practice drawing. When copying, in order to achieve the same line as the original line, I will be very nervous, for fear that the drawing will be crooked. So when holding the pen, he unconsciously held the pen very tightly. It's not about practicing Chinese calligraphy. Don't be so serious.

The pen tablet has a sensitive pressure sensitivity, just place the pen tip on the tablet and draw lightly, and the lines will jump out of the canvas. If you apply too much force, not only the line drawing is not smooth, but also the pen tip and the tablet surface may be scratched. When painting, let the five fingers and arms relax a bit, and the painting will be smoother.

2. The fulcrum of painting

Many people write graffiti and use the second joint of their little finger to control the direction of the pen. Others use the wrist to draw very smooth lines, but there is a drawback that the radius from the wrist to the tip of the pen is too short, not suitable for drawing long lines.

So if you want to draw a long line, there are two ways. The first is to practice using the elbow to focus. When the elbow is exerted, the elbow is used as a fulcrum for drawing exercises. There may be unaccustomed to it at first. Just as it is used to hold the chopsticks forward, if you want to hold the chopsticks backward, it will not hold the dishes firmly. This can be practiced slowly first.

3. The lines must be made in one go

When drawing a line, it is usually done in one stroke. For example, when drawing curvaceous hair for anime characters, draw the arc as much as possible instead of

drawing the line little by little.

If you cannot control the subtle direction changes of the line when drawing a long line, then enlarge the canvas and draw the long line by wiring. When wiring, pay attention to the weight of the line, light at both ends and heavy in the middle, so that the feeling of line faults is not easy to appear when wiring.

4. Practice the feel of the board drawing

After mastering the drawing method of lines, the next step is to practice line drawing. At the beginning, you can find some line drafts with clean lines and clear structures for copying. In the middle and late stages, you can find some relatively complicated lines for practice. In fact, the most important thing is to practice, even if it starts from the trace.

Tablet drawing tutorial: How to teach yourself how to draw with a tablet?

Today I will share with you a tablet drawing tutorial, mainly to teach you how to teach yourself how to draw a tablet! If you like painting, you must want to create a character of your own, a handsome little brother, a smart little sister. However, the ideal is very full, the reality is very skinny, many times we often have many annoying problems in the painting process, such as long arms, small heads, and even the basic digital tablet painting software can't figure it out... So what are the ways to teach yourself to paint on the tablet?

One: Various types of network tablet drawing tutorials

There are a lot of tablet painting tutorials, tips and tricks, you can learn whatever you want to learn, pictures and videos, all kinds of methods, the most important thing is to distinguish the quality of the tablet painting tutorials, and what is the most important thing. suit myself? Don't turn into it in the end: just look at it, and draw it away... After all, tablet painting is more logical!

Two: Pen tablet drawing tutorial book learning

Buy a professional pen tablet drawing tutorial book, but most of the young people who start by self-learning pen tablet drawing can hardly understand a large number of highly professional graphics and texts. It is difficult to stick to it without anyone's guidance, so this is not the case. Too recommended, and the book is dead, this is a lot of people's personal experience, of course, can read and learn is also worthy of our admiration, after all, this requires a certain amount of patience!

Three: Enter the digital tablet painting circle to learn

You can make some good friends or enter the pen tablet drawing learning circle to discuss the methods of pen tablet drawing learning, but don't take the mentality of rushing to the doctor for a sudden illness, like to participate in various online and offline friendship circles, if you don't understand, just ask, but yourself Even the people in the group don't know what their strengths are, and the answers they get are not reliable, and they use them with an ignorant mentality, so you must know how to distinguish this!

4: Enroll in the tablet drawing class

At present, all kinds of digital tablet drawing training classes and online courses are flooded in China. No matter whether they have gold content or not, they can be taught. Therefore, everyone must know how to distinguish. Take a look at the class time. If the class time is less than 200 hours, don't think about it. Remember, it is the class time, the teacher's real class time.

What should I do with a zero-based computer graphic tablet painting?

Today I will give you a detailed start from the beginning~~ The first is the digital tablet. The beginners can buy a hand-painted version of less than one thousand to meet their needs. The first thing to buy the board is to install the driver, otherwise go to the official website. Find the version and model number, or use the CD to install, usually there is a driver CD.

The software sai and ps are quite common, but you have to charge a fee. You can also find free versions of sai and ps when you look for resources online. You can also search for a lot of brushes. The first difficulty of board painting is hand trembling, no matter how good the foundation is, it is difficult to show a normal level of painting when first contacting board painting, so don't be discouraged.

It is completely possible to learn board drawing with zero foundation, but in the process of learning, you need to supplement the knowledge of painting according to your needs.

The more practical knowledge of painting in the early stage is: the composition of the sketch, which is helpful for shaping; the basic proportions of the human body, including the three courts and five eyes, the proportions of men and women; the muscle distribution of the human body, you need to understand some basic muscles and muscle groups . At least don't draw the human body too crookedly.

Do not sharpen the line when drawing on the board. It is easy for beginners to sharpen the line. If the line is not well drawn, cancel and redraw. Beginners recommend using SAI, but it is not recommended to use too much for hand-shake correction. Generally, it is less than 5, and I use 3.

Most of the bottlenecks encountered in board painting are because of the lack of basic painting skills. It is not that you can't hand-paint, but that there is no concept of light and shade of sketch, no concept of color. All these knowledge need to be accumulated, and you can learn while painting.

Painting is a relatively boring thing [it is true]. If beginners want to draw the second dimension, they can copy some fan pictures that they are interested in. It is easy to get bored if you just walk from still life sketches and plaster statues.

When drawing with SAI and PS, especially the hook line, the brush should not be too thick. It is best to use a thinner pen for the line draft. Don't cling to the brush, the brush can't save the handicapped.

You have to persevere in painting. Don't expect to paint a complete work in a few hours. The big guys have dozens of hours for each work, so be patient. It's best to draw a little every day, so that it won't be hand-crafted.

Use your brain to copy, don't copy foolishly, think about the layout of the copy and the shape of the human body, and keep it in mind. The most important thing in painting is to practice more. It took four or five years for many big guys to paint before reaching their current level.

Alright, the sharing of this issue is over here, friends who like painting must stick to it.