

REMOTE CONTROL EXTENDER

PLEASE READ BEFORE USE

Congratulations on your new purchase! Your new Around the House RF (radio frequency) Remote Extender uses the most advanced technology. By installing the battery size transmitter inside your existing remote control's battery compartment, you have instantly converted your standard IR (infrared) remote to an RF remote. This will extend your existing remote's operating range thru doors, walls, windows, floors, cabinets, and closets. The extender allows remote operation without the need to point the remote in the direction of your electronic devices.

SETUP & OPERATION INSTRUCTIONS:

Charging the Batteries:

NOTE: Please allow batteries to charge for 24-36 hours before initial use.

1. Place one of the mini rechargeable batteries into the RF transmitter so that the flat end is exposed as shown here:



2. Your Flying Saucer unit (RF Receiver) also serves as your mini battery charger. Place both the assembled transmitter and the spare mini battery into the bottom of your the Flying Saucer for charging.




3. Plug the RF Extender into the wall using the AC adapter. **CHARGE 24-36 Hrs.**

Note: After charging, use the Assembled Transmitter for your remote control as described below. Leave the extra mini battery in charger to swap out when you need a fresh-charged battery. DO NOT use alkaline batteries in charger as it may cause damage to the receiver.

Placing the batteries into your remote control:

4. If your remote control uses AA batteries, place the assembled transmitter (w/battery) into the AA plastic sleeve. If the remote control is AAA you will only need the Assembled Transmitter.



Replace (1) AA or AAA battery from your existing remote control with either the Assembled Transmitter with AA sleeve or just the Assembled Transmitter depending on your remote's battery type.



Final Setup:

5. Plug in Flying Saucer unit and insert the single IR (infrared) emitter cord into the back of the unit. Then position the purple emitter "bulb" in the front of your audio/video equipment by your equipment's IR (infrared) sensor. Remove the adhesive tape on the bottom of the IR emitter to secure. **NOTE:** When using the eye emitter, the Flying saucer unit may be anywhere inside a cabinet or closet (3-eye & 6-eye emitters sold separately for multiple components). You may also use your Flying Saucer unit to blast the infrared signal to multiple components if placed facing them within a 15 ft. clear-line-of-site.

Single IR Emitter Cord



Tips & other notes:

- If using the extender with a cable box, you may need to switch the setting to A. The settings are located on the bottom of the Flying Saucer Receiver inside the charger housing.
- You may sometimes need to adjust the position of the RF transmitter inside your remote for better RF performance.
- If your remote control is functioning at a lesser distance than normal, the battery needs recharging. Swap mini battery with charged battery located in your Flying Saucer's charging dock.

3 and 6 eye emitters, a stand alone USB charger, and additional transmitters are also available.

Care

Keep the extender dry. If it gets wet, wipe dry immediately. Use and store the extender only in normal temperature environments. Handle the extender carefully; do not drop it. Keep the extender away from dust and dirt, and wipe it with a damp cloth occasionally to keep it looking new.

F.C.C. Caution

This device complies with FCC rule part 15. Operation is subject to the following conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Specifications:

Operating range:	Up to 100+ feet (30 Meters)
Operating frequency:	433.92 MHz and 418 MHz
FCC ID:	SB7AAA
IC #:	5216A-AAA
A/C Adapter Voltage:	
Input:	110V AC, 60HZ
Output:	DC 12V, minimum 100mA
Battery:	1.5V 2/3 AAA (Rechargeable)

U.S. Patent # 6, 400, 480 and other worldwide patents pending. © 2001, 2002, 2003, 2004, 2005, 2006, 2007, 2008 All Rights Reserved

LIMITED WARRANTY: Next Generation Home Products, LLC (NGHP) warrants this product against defects in workmanship for one year from the date of purchase. During this warranty period, this product will be repaired or replaced, at NGHP's option, without charge. Please read your instructions thoroughly and use this product only as directed. This warranty does not cover any damage due to commercial use, accidents, misuse, abuse or negligence. This warranty is valid only in the United States of America. Repair or replacement as provided under this warranty is the exclusive remedy of the consumer. NGHP shall not be liable for any incidental or consequential damages for breach of any expressed or implied warranty of this product, except to the extent prohibited by applicable law. Any implied warranty of merchantability or fitness for a particular purpose on the product is limited to the duration of this warranty.

AUTHORIZED SALES:

NextGen
8064 Washington St. / Port Richey, Fl. 34668
tel: 727.834.9400 fax: 727.846.1788
email: sales@nextgen.us
www.nextgen.us

