

GENERAL BATTERY PRECAUTIONS

- Never use or charge a battery if it appears to be leaking, discolored, deformed, or in any way abnormal.
- Do not mix old and new batteries, and do not mix alkaline, carbon-zinc or rechargeable nickel-cadmium batteries
- Use only new batteries of the type recommended
- Avoid charging a rechargeable battery when the temperature is not within 5°C - 35°C (41° - 95° Fahrenheit).
- Never expose a battery to any liquid.
- Never expose a battery to excessive heat such as direct sunlight or fire. Never use a battery pack in an unventilated vehicle where excessive internal temperatures may be encountered.
- Always keep batteries out of the reach of infants and small children.
- Remove batteries if device will not be used for a prolonged period to avoid corrosion which can damage the unit
- Dispose of batteries that are leaking

Dispose of batteries in accordance with local regulations

Setup cannot be completed?

- Make sure you are using a 2.4GHz 802.11b/g/n network.
- The device supports WPA/WPA2 PERSONAL encryption and OPEN. It is not compatible with Enterprise Wi-Fi Networks such as in colleges or businesses.
- Connect your smartphone to the same Wi-Fi network that you intend to connect the sensor.
- Make sure your smartphone and device are near the access point (router) to make sure you have good signal strength.