Cuisinart

Reusable Filter Cup

How to Use with Your Single-Serve Coffeemaker:

- Open HomeBarista™ capsule, fill with ground coffee or tea and close lid. Note: Maximum fill is 15 grams (2½ tablespoons).
- Remove capsule holder from brewing chamber and replace with filled HomeBarista¹⁸ Filter Cup.
- 3. Close brewing chamber, brew and enjoy!

MODEL SS-RFC