

Projection Alarm Clock

User Manual

• 6 Months Return

• 24 Months Warranty

• Lifetime Support

Before use

Thanks a lot for choosing our product. Please read the following information carefully:
1. This product is designed to be used with the original adaptor provided in the package.
2. The built-in button battery inside the product is only for time backup in case of a power outage.
3. Please follow the instructions to set up the product.
We hope you have a nice experience using our product.

Precautions

1. Do not expose the unit to extreme temperatures, direct sunlight, dust or humidity.
2. A cloth or other protective material should be placed between the clock and the furniture.
3. Cut off the power before cleaning the clock with a soft cloth moistened only with mild soap and water.
4. You must use the original adapter.
5. Do not disassemble the clock or touch any components.

Chapter 1

Package Contents

12:39

x1

x1

x1

USER MANUAL

x1

Chapter 2

Diagram

1

2

3

4

5

6

7

8

9

10

11

12

Chapter 3

Specifications

Input:	5V $\pm$ 1.5A	USB output:	5V $\pm$ 1A
Projection angle:	-90°—90°	Projection distance:	0.5-3m
Screen brightness:	3level	Projection brightness:	3level

Chapter 4

Power On

Connect the USB cable to the product and adapter, and plug the adapter into a power outlet.

Chapter 5

Time Setting

1. Long press to enter to time setting, then short press to set MINUTES. (Short press / to set the time, and long press / to quickly set the time.)

2. After setting, short press to confirm and back to Time Display.

3. In Time Display Mode, short press to switch 12/24-hour time format. The **"AM"** appears on the display in the forenoon and the **"PM"** appears in the afternoon if you choose the 12-hour time format.

Note: If the setting is completed and no operation for 15s, the clock will automatically save the setting and back to Time Display.outlet.

Chapter 6

Alarm Setting

1. Long press to enter to Alarm Hour setting, short press again to enter to Alarm Minute setting. (Short press / to set alarm time, and long press to quickly set the time.)

2. After setting, short press to confirm and back to display mode.

3. In Time Display Mode, short press to turn on/off the alarm.

Note: If the setting is completed, and no operation for 15s, the setting will be automatically saved and clock returns to the time display interface.

• Snooze Function

When the alarm rings, short press to turn off the alarm briefly, and it will alarm again after 9 minutes.

• Turning off the alarm

When alarm rings, press any button other than to turn off the alarm.,
Note: The alarm is only turned off for the day. It goes off again the next day.

Chapter 7

Display Brightness Adjustment

In Time Display Mode, short press to adjust display brightness. Low-Medium-High-OFF.

Chapter 8

Projection setting

• Brightness adjustment

1. Short press to turn on projection, then short press again to adjust brightness of projection.dim-mid-high.

2. When the projection is turned on, long press to flip projection image 180°.

Note: The most recommended distance for projection is 0.5-3m.

Short press

Long press

• Adjust the projection angle

Rotate the cylinder to adjust the projection angle. Range: -90°—90°

Chapter 9

USB Charging Function

Connect the USB port of this product with USB cable to charge the mobile phone and other devices.

Note:

1. Please use the original USB cable of the mobile phone and other devices to charge.

2. Please power the product with the original adapter supplied.

3. It may take longer time to charge your phone by using this USB port.

FCC statement

Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) This device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

• Reorient or relocate the receiving antenna.

• Increase the separation between the equipment and receiver.

• Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

• Consult the dealer or an experienced radio/TV technician for help.