

INSTRUCTIONS FOR USE

1. Flip ring up to open
2. Flip ring down to lock and seal
3. Our containers are intended for dry food storage
4. Please notice that these containers can't be put in microwave and refrigerator
5. The bearable temperature range is 32--158 degrees Fahrenheit

INSTRUCTIONS FOR CLEANING



1. Press down the lid



2. Remove the ring from center slot



3. Separate the top and bottom cover



4. Remove silicone gasket from the bottom of lid



5. Please hand wash all parts and dry them with a paper towel



6. Make sure to insert silicone gasket in correct position when reassembling