

MB-395B user manual

Introduction


Thank you for using our company's products , in order to enable you to operate the speaker as easy as possible. Please read this manual carefully before you begin to use it.

The Speaker is a fashion portable wireless bluetooth speaker with water proof designed, **This speaker can bear the rain..it is very suitable for outdoor travel.** Support bluetooth 5.0 protocol, support for smartphones, tablets, notebooks that with bluetooth audio equipment , allowing you to completely get rid of a wire harness restraint, freely enjoy music , and without bluetooth mobile phones, notebook computers, MP3, MP4 and other audio input equipment.

Points for attention

- *Do not hit or crush it seriously.
- *Do not contact benzene, diluent and other chemicals.
- * Do not use near by strong magnetic field or electric field.
- * Avoid direct rays or heating appliances.
- * Do not disassemble, repair or modify.
- * Do not listen at large volume for long periods of time, so as not to injure the hearing.
- ***Do not clean the speaker with water and don't immerse the speaker in the water. This speaker only has water spray prevention function. If use the speaker not by the right way and cause any quality problems, not support warranty. Kindly note above!. Please clean the speaker with a slightly damp cloth.**
- * **when using cycling, driving a car or motorcycle, Please don't stand in the rain for a long time**
- * when using at low voltage, it may cause distortion of sound and please charge it in time.
- * Bluetooth is compatible with common smart phones and tablets, but depending on the device or application you use, may not be able to support a particular feature.

Buttons information with Interface:



1. Long press Off/on, short press switch modes to Bluetooth and Aux
2. **1.** short press to pause/ tell ,pause/ play; **2.**Long press to cancel or set-up TWS function
- 3.**3.**Double click last No to redial, short press pause/ play; When incoming call, short press answer/hang up , long press reject
3. previous song/ **volume up** Short press to previous song, long press to **up** volume
4. Next song /**volume down** Short press to next song, long press to **down** volume
5. Dc 5V Charger interface
6. AUX in

Bluetooth mode

1 Bluetooth version: Bluetooth 5.0, supports HSP,HFP,A2DP protocol, with English prompt voice, and bluetooth device name **BT SPEAKER**

2 Press switch button (2 seconds), on or off. After the opening, speaker makes a prompt voice, the blue light flashes quickly, and the speaker goes into bluetooth mode.

3 The blue light flashes by quick into the matching state and the phone searches for the name of the **BT SPEAKER** device to connect. If you need the password, enter it(0000), when the connection is successful the blue light is always bright and speaker indicate a successful sound. The blue light flashes slowly during the music playing . Once the paired phone turns on bluetooth and then automatically reconnects the speakers.

AUX In mode

1. Insert AUX In automatically into AUX In mode and the blue light flashing by

How to set-up TWS function:

Power on two same speakers at same time. And make sure the two same speakers are in bluetooth mode. Two same speakers will pair bluetooth each other automatically. You will hear indication voice "Done" around 3 seconds later. It means TWS function set-up successfully. If want to cancel or set-up TWS function again, just keep pressing the Play/Pause button 3 seconds

Charging

1 Plug the USB cable into the speaker connect to the 5V charger or computer to charge the speaker

2 When charging, the "charging" red indicator light on when it is full the red light is out.

Other

1. The default volume of the speaker is 2/3 of the total volume .To protect battery life and speakers work, so the software Settings when the battery voltage is lower than 3.3 V speakers will automatically detect the concurrent give out sound prompt alarm, when battery voltage is lower than 3.3 V the speaker makes a voice prompt and set up automatic shutdown meantime.

2. When the speaker standstill, the speaker will power off automatically if not use the speaker 10 minutes. **If need play again ,needs to power on the speaker again.**

List of key functions

	Buttons			
Mode	▶	⏻	-	+
Bluetooth mode	1. short press to pause/ play; 2.Long press to cancel or set-up TWS function 3.Double click last No to redial, short press pause/ play; When incoming call, short press answer/hang up , long press reject	Long press to on/off , short press switch modes (when switching mode, needs to be inserted into the audio line otherwise it will not be valid).	Short press to previous song, long press to down volume	Short press to next song, long press to up volume
AUX IN	Short press to pause/ play	Short press to switch mode	Long press to down volume	Long press to up volume

Specification parameters:

MB-395B

2. Bluetooth Range: 15 meters

3. Output power: RMS 10W(5W*2)

2pcs

6. Built-in battery: 1800mAh/3.7V

8. Signal to noise ratio: ≥65 dB

10. Charge time : 2.5-3.5H

11. waterproof IPX7

call/AUX /BLUETOOTH/ TWS Function/TF/USB

product size: 75*75*150mm

Package Includes

1: Speaker x 1 pcs

2: Micro USB Charging Cable x1 pcs

1. Bluetooth Version: **V5.0** Chip :JL

4. Driver Size: 52 mm *

5. Frequency response: 100 Hz-20 KHZ

7. Sensitivity: 84±2 dB

9. Distortion: 1%

12. Function : Hands-free

3: Attach line of the speaker x1 pcs

4: User Manual x 1 pcs