

Troubleshooting

- Do not over inflate the airbed. Stop inflating once the airbed is fully expanded and firm
- Make sure that the airbed is laid on a level surface free from stones and sharp objects. Bed may tip over on uneven surfaces
- Inspect the power cord regularly. Do not use the airbed if the power cord or plug is damaged
- Do not attempt to disassemble, repair, or service the pump. No serviceable parts are contained inside
- Never run the pump for longer than 10 minutes at a time. Let the motor cool down for 5 minutes before using it again. Disconnect the plug when the pump is not in use
- Do not block air intake during operation, this could damage the motor
- In case of a puncture, a repair patch has been included. Please follow repair instructions carefully