

 **Health Warning**

Use of a keyboard or pointing device may be linked to serious injuries or disorders.

When using a computer, as with many activities, you may experience occasional discomfort in your hands, arms, shoulders, neck, or other parts of your body. However, if you experience symptoms such as persistent or recurring discomfort, pain, throbbing, aching, tingling, numbness, burning sensation, or stiffness, **DO NOT IGNORE THESE WARNING SIGNS. PROMPTLY SEE A QUALIFIED HEALTH PROFESSIONAL**, even if symptoms occur when you are not working at your computer. Symptoms such as these can be associated with painful and sometimes permanently disabling injuries or disorders of the nerves, muscles, tendons, or other parts of the body. These musculoskeletal disorders (MSDs) include carpal tunnel syndrome, tendonitis, tenosynovitis, and other conditions.

While researchers are not yet able to answer many questions about MSDs, there is general agreement that many factors may be linked to their occurrence, including: medical and physical conditions, stress and how one copes with it, overall health, and how a person positions and uses his or her body during work and other activities (including use of a keyboard or pointing device). Some studies suggest that the amount of time a person uses a keyboard may also be a factor. Some guidelines that may help you work more comfortably with your computer and possibly reduce your risk of experiencing an MSD can be found in the "Healthy Computing Guide" topic of the User's Guide, provided with the software program on your CD-ROM. If you do not have the CD-ROM for this product, you can access the "Healthy Computing Guide" at <http://www.microsoft.com/hardware/>, or (in the United States only) call 1-800-360-7561 to request a CD-ROM at no charge. If you have questions about how your own lifestyle, activities, or medical or physical condition may be related to MSDs, see a qualified health professional.

**About Your Rights and Obligations**

The software with this product is licensed, not sold. You must either agree to the license contract in the software Setup screens or promptly return the entire product for a refund, excluding return costs. After you install the software, you may consult the license and the Limited Warranty for the product at any time by looking in the "Legal Information" section of the User's Guide. You may also print a copy for your records.

---

Information in this document, including URL and other Internet Web site references, is subject to change without notice. Unless otherwise noted, the example companies, organizations, products, people and events depicted herein are fictitious and no association with any real company, organization, product, person or event is intended or should be inferred. Complying with all applicable copyright laws is the responsibility of the user. Without limiting the rights under copyright, no part of this document may be reproduced, stored in or introduced into a retrieval system, or transmitted in any form or by any means (electronic, mechanical, photocopying, recording, or otherwise), or for any purpose, without the express written permission of Microsoft Corporation.

Microsoft may have patents, patent applications, trademarks, copyrights, or other intellectual property rights covering subject matter in this document. Except as expressly provided in any written license agreement from Microsoft, the furnishing of this document does not give you any license to these patents, trademarks, copyrights, or other intellectual property.

©1999–2002 Microsoft Corporation. All rights reserved.

Microsoft, Natural, and Windows are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries.

The names of actual companies and products mentioned herein may be the trademarks of their respective owners.

02/02 Part No. X08-73106

**Troubleshooting**

If you have a question about your Microsoft keyboard, try the following:

- View the User's Guide installed with IntelliType Pro software, which contains product information and troubleshooting tips.
- Look in Readme.txt on the IntelliType Pro CD-ROM for late-breaking product information (Windows version only).
- Go to the Microsoft Keyboard Web site at: <http://www.microsoft.com/keyboard/> for additional product information and IntelliType Pro software updates.
- See the "Product Support" section of the User's Guide, or go to: <http://support.microsoft.com/directory/> for information about how to contact Microsoft Product Support Services.

**Product Information and Software Updates**

For general Microsoft keyboard product information and IntelliType Pro software updates, go to the Microsoft Keyboard Web site at: <http://www.microsoft.com/keyboard/>

**Regulatory Information**

This product was tested and complies with the limits for a Class B digital device under Part 15 of the U.S. Federal Communications Commission (FCC) rules, and is subject to these conditions: It may not cause harmful interference and must accept any interference received, including any that causes undesired operation.

This Class B digital apparatus complies with ICES-003.

Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.

For detailed information on U.S. and Canadian radio interference regulations, search for "regulations" in the User's Guide installed with IntelliType Pro software.



# Getting Started

## Microsoft Keyboards

[www.microsoft.com/keyboard](http://www.microsoft.com/keyboard)

## Windows

### 1 Important! Install IntelliType Pro Software

IntelliType Pro software enables the unique features of your keyboard and lets you customize it to fit your working style.

#### To install IntelliType Pro software

- 1 Insert the Microsoft IntelliType Pro compact disc into your computer's CD-ROM drive.

If Setup does not start automatically, do the following:

- Click the **Start** button, and then click **Run**.
- Type `[drive]:setup`. For example, if your CD-ROM drive is drive E, type `e:setup`



- 2 Follow the Setup Wizard instructions on your screen. Depending on your operating system version, you may be asked to restart your computer before Setup can begin.

- 3 After installation is complete, restart your computer if prompted to do so. The Quick Start Guide will automatically open to help you learn about the keyboard features.

#### To start IntelliType Pro software

- Click **Start**, point to **Programs** (or **All Programs**, depending on your operating system), click **Microsoft Keyboard**, and then click the **IntelliType Pro Key Settings** tab.

To open the Microsoft Keyboard User's Guide, click the **Help** button on the IntelliType Pro **Key Settings** tab.



### 2 Connect Your Keyboard

#### PS/2 Connection (recommended)

- 1 Shut down and turn off your computer.
- 2 If your keyboard cable has a round **PS/2 connector**, plug it into your computer's round PS/2 keyboard port.

If your keyboard cable has a **USB-to-PS/2 adaptor**, attach it to the Universal Serial Bus (USB) connector, and then plug it into your computer's round PS/2 keyboard port.

- 3 Turn on your computer.

#### USB Connection (advanced and laptop users only)

If your keyboard has a Universal Serial Bus (USB) connector, you can plug it into your computer's USB port. However, a PS/2 connection is recommended because some computers do not fully support USB keyboards.

- With your computer turned on, plug the rectangular **USB connector** into your computer's rectangular USB port.

## Macintosh

### 1 Important! Install IntelliType Pro Software

#### To install IntelliType Pro software

- Insert the Microsoft IntelliType Pro compact disc into your computer's CD-ROM drive, double-click the Microsoft Keyboard Installer icon, and then follow the on-screen instructions.

#### To start IntelliType Pro software

- Click the **Apple** menu, point to **Control Panels** (or click **System Preferences**, depending on your operating system version), and then click **Microsoft Keyboard**.

To open the User's Guide, click **Microsoft Keyboard User's Guide** on the **Help** menu.



### 2 Connect Your Keyboard

If your keyboard has a Universal Serial Bus (USB) connector, it can be used with a Macintosh computer.

- With the computer turned on, plug the rectangular **USB connector** into your computer's rectangular USB port.

### Adjusting the Keyboard Legs

The keyboard legs are designed to accommodate various body sizes, chairs, and desks.

- Pull out or push in the keyboard legs to a position that minimizes bending of your wrists while typing.

### Connecting the Keyboard Palm Rest

The keyboard palm rest is available on certain keyboard models only.

- On a level surface, insert the tabs on the palm rest into the slots on the front of the keyboard, and then snap them together.

### Getting Help

The Microsoft Keyboard User's Guide is your complete product information source and it is installed with IntelliType Pro keyboard software. It contains important product information in a searchable format, including:

- Microsoft keyboard and IntelliType Pro feature descriptions and instructions
- End-User License Agreement (EULA), Limited Warranty, and regulatory information
- Troubleshooting and Product Support Services information

#### To open the User's Guide

- **Windows:** Click **Start**, point to **Programs** (or **All Programs**, depending on the operating system version), click **Microsoft Keyboard**, and then click the **Help** button on the **Key Settings** tab.
- **Macintosh:** Click the **Apple** menu, point to **Control Panels** (or click **System Preferences**, depending on the operating system version), click **Microsoft Keyboard**, and then click **Microsoft Keyboard User's Guide** on the **Help** menu.

### What the Keyboard Lights Mean

The keyboard lights indicate the status of the toggle keys, such as NUM LOCK or CAPS LOCK. For example, if NUM LOCK is on, the NUM LOCK light is on; if CAPS LOCK is off, the CAPS LOCK light is off. Certain keyboard models may use on-screen display (rather than a light) to indicate the status of the SCROLL LOCK toggle key.

### Using the F LOCK Key (certain keyboard models only)

The F LOCK toggle key gives you more functionality by providing two command modes for the top row of keys. When F LOCK is off (F LOCK light off), the enhanced commands printed on the top of the keys are enabled. When F LOCK is on (F LOCK light on), the standard commands printed on the front of the keys are enabled.

Depending on your keyboard model, you may need to turn F LOCK on (F LOCK light on) to access the NUM LOCK toggle key, as well as other system key commands labeled on the front of the keys, such as INSERT, PRINT SCREEN, and SCROLL LOCK.