

### 3. Intended Use

- ▶ This battery pack is only intended to be used with Denali tools indicated in chapter "Specifications".
- ▶ This battery pack can only be charged with a Denali 20V Charger.
- ▶ This battery pack is intended for household use only.
- ▶ This battery pack is intended to be used in dry locations only. Do not expose to rain, water and excessive humidity.

### 4. Before First Use

#### **⚠ DANGER Risk of suffocation!**

Keep any packaging materials away from children and pets – these materials are a potential source of danger, e.g. suffocation.

- ▶ Remove all the packing materials.
- ▶ Remove and review all components before use.
- ▶ Check the battery pack for transport damages.

### 5. Use

#### 5.1 Charging the battery pack

#### **⚠ CAUTION Risk of injury and fire!**

Use this battery pack only with specifically designated chargers. Use of any other chargers may create a risk of injury and fire.