

Functionality Issues:

The description Indications:

- * Duo, the number 1 selling multi-cooker, combines 7 kitchen appliances in 1, Pressure Cooker, Slow Cooker, Rice Cooker, Steamer, Sauté, Yogurt Maker and Warmer, prepares dishes up to 70% faster to support your busy lifestyle
- * Features 14 Smart Programs - Soup, Meat/Stew, Bean/Chili, Poultry, Sauté/Simmer, Rice, Multigrain, Porridge, Steam, Slow Cook, Keep Warm, Yogurt, Manual, and Pressure Cook. Now, your favorite dishes are as easy as pressing a button
- * Healthy, stainless steel (18/8) inner cooking pot made from food grade 304, no chemical coating, 3-ply bottom for even heat distribution, fully sealed environment traps the flavors, nutrients and aromas within the food
- * Built with the latest 3rd generation technology, the microprocessor monitors pressure, temperature, keeps time, and adjusts heating intensity and duration to achieve your desired results every time
- * UL and ULC certified with 10 safety mechanisms to provide you with added assurance, designed to eliminate many common errors
- * Accessories include, stainless steel steam rack with handles, rice paddle, soup spoon, measuring cup, condensation collector and recipe booklet. To maximize performance of cooker only use genuine Instant Pot accessories

Slow Cooking:

1. Follow steps in the "Cooking Preparation" section of this manual. The steam release handle should be at the "Venting" positions. An optional glass lid can also be used.
2. Connect power cord. The LED display shows "OFF" indicating that it's in standby state.
3. Press "Slow Cook" key.
4. Change cooking duration between 0.5 and 20 hours by pressing the "+" or "-" key.
5. Select the desired cooking mode with the "Adjust" key. By pushing the "Adjust" key repeatedly, you can adjust the cooking mode to "Normal", "More" and "Less" modes, which correspond to medium, high and low in a common slow cooker.
6. Cooking starts automatically in 10 seconds after the last key is pressed.
7. When the cooking finishes, the cooker beeps and goes into the Auto "Keep Warm" cycle for 10 hours.