

Subject : New firmware for WH16NS40

Content Title 1 [Critical Instructions&How to update the firmware]

1. Warnings and Notifications

- Do not open any programs or start any system functions during the update, as they will interfere with data transfer and damage the drive.
Do not cancel the operation once it has been started or the drive will become permanently damaged, as a result.

- If firmware is not installed properly as guided below, your drive will be damaged permanently, and LG will not be responsible for it.

- Could please check model number which you have.
If your driver is not the WH14NS40, the firmware is not updated.

- The drives must be original LG branded drives with BD-Writer model number WH16NS40(no OEM units).

- If you have an OEM unit, branded with another manufacturers name,
Please contact that manufacturer for support and firmware updates.

- This firmware update is for use only on PC's with Windows 10, 8/8.1, 7.

2.Improvement Point

iβ Model : WH16NS40

iβ Version : N1.03

iβ Improvement Point : Improved BD disc compatibility

3.How to update the firmware

1)Download and unzip the file WH16NS40.ZIP to a folder of your choice.

3)Close all other programs including: screen saver, antivirus and/or power-down programs.

(If these programs are not closed, they will try to engage the PC, during the update process, thus interrupting the update and damaging the drive).

4)Check the drive to ensure that there is no disk in the tray before you start the update procedure.

5)Go into the folder with the update file and double click the WH16NS40.exe program and click the i°updatei± button (red). Once the update is complete, you will see i°Firmware Update Completei± and the button will become green and advise you to reboot the system. You will need to reboot your PC.