

Connect the USB Audio adapter to your system.

Install the latest drivers from our website here:

https://www.vantecusa.com/CKEdit/images/files/nba-200u_v8182166.zip

After install, reboot system. You will see this icon on the bottom right



Click on the blue/white icon to show the “USB Multi-Channel Audio Device” setting Window

1) select 8 CH

2) skip 2 and 3 or now

4) Analog Output set to 7.1 Speakers

Plug all your speakers to all the ports on the audio adapter

Click on each speaker icon to hear test sound for 5,6,7,8,9,10,11,12 speakers

If you do not have all the speakers to test, use earbuds shown to test each port.



Next Select the bottom left Windows Start icon, pick Setting, pick System, pick sound.

A) check to make sure Speakers (USB Multi-Channel Audio.. is selected

B) select Sound Control Panel

Should see the Sound panel with Playback tab showing speakers

C) Select the speakers (must show it is using USB Multi-Channel Audio Device)

D) Make sure it is Green Checked, meaning it is the default speakers

E) If it is not the default, please check on E to make it the default

F) click F to configure

G) should see Speaker setup

H) if not selected, select 7.1 Surround

I) click test to hear sound and speakers actively playing the test tone on J, K, L, M, N, O, P, Q

You can also test individual speakers by clicking on any speakers.

