

CLEANING AND MAINTENANCE

1. Always disconnect the hair straightener power plug from the wall socket and allow it to cool down completely before any cleaning operation.
2. Do not use abrasive cleaning agents or scrub pads. Do not use alcohol or solvents.
3. Wipe the main body and the ceramic plates with a slightly damp cloth and dry with a soft cloth.
4. Never immerse the appliance in water or any other liquid.

CAUTIONS

1. Don't touch the straightening plates when it is on or hot.
2. The straightening plates can cause burns. Avoid direct contact with the skin and eyes. Never pack the straightener when hot.
3. Do not use the straightener in case the power cord is damaged else it may cause electric shock.
4. Protect the straightener from moisture. Never put it into the dishwasher.
5. The improper use of the hair straightener may cause damage to your hairs.
6. High temperature can be reached in just a few seconds but dropping down of temperature may take longer time.
7. Never wrap the cord around the straightener.
8. The cord should not come into direct contact with hot parts and should never run in between the straightening plates.
9. Insert main cable plug to power supply ONLY when the straightener is switched off.

WARNING

1. Do not use this straightener near bathtubs, showers, basins or other vessels containing water.
2. The heating plates have coating. This coating might slowly wear away over time. However, this does not affect the performance of the appliance.



GUARANTEE

Havells Personal Grooming products are guaranteed against manufacturing defect for a period of Two Years from the date of purchase. The defective product will be repaired/replaced within guarantee period free of cost provided it is sent (freight paid), securely packed to our nearest authorized dealer/service center along with the purchase bill and guarantee card duly filled in and stamped by the selling dealer. Damaged/broken or worn-out parts will be charged basis company's list price.

The guarantee is valid subject to the following:

1. The product is used and maintained properly and the damage is not due to negligence, mishandling, topping or falling off of the product, distorted/damaged blades, accident and attempted repairs by unauthorized persons.
2. The product is purchased from Havells authorized dealers/retailers only.
3. The serial number of the product is not missing, deleted, defaced or altered.
4. The product is used for personal/ domestic purpose only.

The guarantee shall not apply:

Havells India Ltd. shall, however, be liable up to the maximum of the price charged for the product and shall have no responsibility for any indirect or consequential damage

Havells India Ltd.
QRG Towers, 2D, Sector -126, Expressway, Noida -
201 304 (UP), Ph. +91-120-3331000,
E-mail: marketing@havells.com, www.havells.com
Consumer Care No.: 1800 11 0303, 1800 103 1313
(All Connections), 011-4186 0303 (Landline)
Join us on Facebook at www.facebook.com/havells
and share your ways to save the planet!

Scan the QR Code
to download
Havells mCatalogue



REGIONAL & BRANCH OFFICES: NORTH - REGIONAL OFFICE: Corporate Office: QRG Towers, 2D, Sector-126, Expressway, Noida-201304, Tel: 0120-3331000, Delhi: Tel: 011-47676700, 23888200, Chandigarh: Tel: 0172-4232400-401, Dehradun: Tel: 0135-6670202, Noida / Haryana: Tel: 0120-3331000, Ludhiana: Tel: 0161-4676000 / 24, Jammu: Tel: 0191-2478330, 2479330, Sri Nagar: Tel: 0194-2490431, Jaipur: Tel: 0141-3914645, 3988210, Jodhpur: Tel: 0291-9214201640 / 45, Lucknow: Tel: 0522-6672100, Kanpur: Tel: 0512-6710400, 6710409 EAST - REGIONAL OFFICE: Kolkata: ICC Tower, 5th Floor, 4 India Exchange Place, Kolkata-700001, Tel: 033-40129851/ 52, Bhubaneswar: Tel: 0674-6668101/102/103/104, Guwahati: Tel: 0361-2134521, 2458923, 2460355, Siliguri: Tel: 0353-2525907, Ranchi: 0651-2244861, 2244862, 2244864, 2244868, 2244869, Jamshedpur: Tel: 0657-6542492, 09234369436, Patna: Tel: 0612-2207221, 2207222, 2207223, 2655518 WEST - REGIONAL OFFICE: Mumbai: 1271, Solitaire Corporate Park, Building No. 12, 7th Floor, Andheri - Ghatkopar Link Road, Chakala, Andheri (East), Mumbai- 400093. Ph: 022 - 67298600-602, Ahmedabad: Tel: 079-40061111, 40060738-740, Indore: Tel: 0731-2572340-41, 4009998 (Airtel), Rajkot: Tel: 0281-2481112, 2921212, Nagpur: Tel: 0712-2240932, 2242692, 2242699, Pune: Tel: 020-64016413 / 14, Raipur: Tel: 0771-4243400 / 01, Surat: Tel: 0261-2350137, 9979890137, Jabalpur: Tel: 0761-4064491 SOUTH - REGIONAL OFFICE: Chennai: Sigapi Achi Building, No. 18 / 3, 6th Floor, Rukmani Lakshminpathy Road, Egmore, Chennai-600008, Tel: 044-42280600, 605, Bangalore: Tel: 080-49075000, Coimbatore: Tel: 0422-4550200, 2305199, 2306199, Hyderabad: Tel: 040-27533372, 27533355, 27533632, 66320407/0408/6401/6402, Kochi: Tel: 0484-4099000, Vizag: Tel: 0891-6514339, Vijayawada: Tel: +91-9247058847/57, Calicut: 0495-4019194, Madurai: 0452-4267022, Trivandrum: 0471-4015323, Hubli: 0836-4248600, Trichy: 09944460160
Representative Offices: • Goa • Solapur • Gwalior • Kathmandu • Bhopal

GUARANTEE CARD

Customer Name _____
Customer Address _____
Pin Code _____
Date of Purchase _____

Dealer's Name & Address

Dealer's Stamp:

Product Model
Hair Straightener
HS4101



Operating Instructions
& Guarantee Card




HAIR STRAIGHTENER
HS4101

Thank you for purchasing Havells Hair Straightener. In order to make you more comfortable while using the product, please read this user manual carefully and keep it for future reference.

OPERATING INSTRUCTIONS

Parts of the straightener


- A. 360° swivel power cord
- B. On/Off switch.
- C. LED power indicator
- D. Ceramic coated heating plates.
- E. Plates lock button



WARNINGS:

1. The product is not intended for use by physically challenged, mentally disabled, or people without knowledge of using the product, unless it is under guidance or supervision of a responsible person.
2. It is generally recommended to put the product out of children's sight, ensure that children do not take the product as a toy.
3. Do not use the product near wound, inflammatory or allergic areas.
4. Do not make any alteration to the product, or give it to unauthorized person for maintenance.
5. Make sure the power plug is dry before using.
6. If product or any part of it is damaged do not re-use.
7. The straightener should never be used near flammable material.
8. Never cover the straightening plates with any other object.
9. The hair straightener is designed to work on ordinary household current only, 100~240 V AC, 50 Hz / 60 Hz. It is not intended for commercial use.

HOW TO USE



1. If locked, slide the plates lock button (E) to unlock position to start using the straightener.
2. Plug the power plug in the socket. Slide the ON/OFF (B) switch button from OFF onto ON to heat up the straightener. The LED (C) light glows.
3. After approx, one minute, the straightener is ready to use.
4. Make sure your hair is completely dry and untangled before you start straightening.
5. Split your hair into small sections.
6. Place the section of hair between the plates (D) and press the straightener to make your hair stay intact.



7. Place the straightener close to the roots of section without burning the scalp.
8. Now, start moving the straightener along with your hair, in upward to downward direction.
9. Run the straightener over the sections until it is completely straight.
10. Carry the same procedure on rest of the sections in the same way.
11. After finish using, when the heating plates (D) cool down, slide the plates lock button (E) to lock position.