support | **Rift**   Go   Gear VR   Guides

Getting Started With Your Oculus Go

Setting Up Your Oculus Go

Which phones can I use with Oculus Go?
How do I download the Oculus app for Oculus Go?
How do I set up my Oculus Go headset?
Where do I find the serial numbers for my Oculus Go?
How do I use the Oculus Go controller?

The Oclus Go controller is a motion controller you can use to interact with apps and games on your Oculus Go. Before you can start using

support   **Rift   Go   Gear VR   Guides**

To pair your controller:

1. Download the Oculus app and follow the onscreen instructions to connect your Go to WiFi.

2. Insert the included battery into your controller, then tap **continue** on the Oculus app.

3. Hold the **Oculus** and **Back** buttons on your controller until the controller LED blinks and then lights up.

4. In the Oculus app, tap **Left** or **Right** to choose which hand you'd like to use and then tap **Continue** to finalize the pairing.

   - You can change which hand you'd like to use by selecting **Handedness** from the controller settings menu in the Oculus app.

Once you've paired your Oculus Go controller, the controller will automatically connect to your headset each time you turn it on, if it's nearby.

To unpair your controller:

1. Open the Oculus app on your phone.

2. Tap **Settings** from the bottom menu.

3. Tap the headset you currently have paired.

4. Tap **Controller**, then tap the controller you currently have paired.

5. Tap **Unpair Controller**.

Once your controller is paired, you can use your controller to interact with apps and games, using the buttons on your controller to do the

support   **Rift**   Go   Gear VR   Guides

- **Touchpad**: Press to select things or swipe to browse
- **Back button**: Press to go back to the previous screen or menu.
- **Oculus button**: Press to go back to Oculus Home or press and hold to reset your controller orientation.
- Press any button to wake the controller after you turn on your headset.

To remove the battery from your Oculus Go controller:

1. Remove the battery cover of your controller by lightly pulling at the bottom half of the controller until it comes loose.
2. Lightly pull on the battery from the bottom end of the controller until it comes loose and can be removed.

Was this answer helpful?   Permalink
    Yes   No

| How do I wear glasses while using my Oculus Go? |
| How do I attach the lanyard to my Oculus Go controller? |
| What do the different lights mean on my Oculus Go headset and controller? |
| How do I turn my Oculus Go off? |
| What charger should I use with my Oculus Go? |
| How do I change my environment on Oculus Go? |

support   **Rift**   Go   Gear VR   Guides

How do I set up a gamepad with Oculus Go?

I'm having trouble connecting or pairing my Oculus Go controller.

How do I use the toolbar menu in VR on Oculus Go?

PRODUCT

Experiences

Rift

Go

Gear VR

Medium

Oculus for Business

DEVELOPERS

Developer Center

Docs

Downloads

Tools

Developer Blog

Developer Forums

COMPANY

Blog

Careers

News

Brand Center

Story Studio

Oculus Connect

Research

COMMUNITY

VR for Good

Launch Pad

Forums

Support

Order History

Download Rift Setup

English (US)

support   **Rift**   Go   Gear VR   Guides