

# microSD Card Compatibility Guide



## Mobile Phones

Brand	Model	1066x microSD	633x microSD	PLAY microSD
<b>OnePlus</b>	Nord N10	✓	✓	✓
	Nord N100	✓	✓	✓
<b>Sony</b>	Xperia 5 II	✓	✓	✓
	Xperia 1 II	✓	✓	✓
<b>Samsung</b>	Galaxy S20+	✓	✓	✓
	Galaxy Note 20 Ultra	✓	✓	✓
	Galaxy Note 10+	✓	✓	✓
	Galaxy A21s	✓	✓	✓
	Galaxy A52	✓	✓	✓
	Galaxy A20s	✓	✓	✓
	Galaxy A71	✓	✓	✓
<b>LG</b>	Stylo 6	✓	✓	✓
	G7 fit	✓	✓	✓
	K31	✓	✓	✓
<b>ZTE</b>	Blade 10	✓	✓	✓
	Axon 10 Pro	✓	✓	✓
<b>Moto</b>	G7 Play	✓	✓	✓
	G power	✓	✓	✓
	one action	✓	✓	✓
<b>Nokia</b>	5.3	✓	✓	✓

## Tablets

Brand	Model	1066x microSD	633x microSD	PLAY microSD
<b>HUAWEI</b>	MatePad 11	✓	✓	✓
	MatePad 10.8	✓	✓	✓
	MatePad 10.4"	✓	✓	✓
	MatePad T 10s	✓	✓	✓
	MatePad T 10s	✓	✓	✓
	MatePad T 8	✓	✓	✓
	MatePad T 8 Kids Edition	✓	✓	✓
	MediaPad M6 10.8"	✓	✓	✓
<b>Surface</b>	Pro 7+(Wi-Fi)	✓	✓	✓
	Pro 7	✓	✓	✓
	Pro 6	✓	✓	✓
	Pro 5	✓	✓	✓
	Go	✓	✓	✓

Brand	Model	1066x microSD	633x microSD	PLAY microSD
<b>Samsung</b>	Galaxy Tab S7+	✓	✓	✓
	Galaxy Tab S7	✓	✓	✓
	Galaxy Tab A7	✓	✓	✓
	Galaxy Book S LTE	✓	✓	✓
	Galaxy Book S Wi-Fi	✓	✓	✓
	Galaxy Tab A 8.4(2020)	✓	✓	✓
	Galaxy Tab A 10.1(2019)	✓	✓	✓
	Galaxy Tab S6	✓	✓	✓
	Galaxy Tab S6 Lite	✓	✓	✓
Galaxy Tab S5e	✓	✓	✓	
<b>Lenovo</b>	Tab P11 Pro	✓	✓	✓
	Tab M10 HD Gen 2	✓	✓	✓
	Tab M10	✓	✓	✓
	Tab M8	✓	✓	✓
	Tab M7	✓	✓	✓
	Smart Tab M10	✓	✓	✓
<b>Ematic</b>	EGQ378	✓	✓	✓
<b>Amazon</b>	Fire HD 10 PLUS	✓	✓	✓
	Fire HD 10	✓	✓	✓
	Fire HD 8	✓	✓	✓
	Fire HD 7	✓	✓	✓

## Action Cameras

Brand	Model	1066x microSD	633x microSD (128GB above)	PLAY microSD
<b>GoPro</b>	Hero 10 Black	✓	✓	
	Hero 9	✓	✓	
	Hero 8	✓	✓	
	Hero 7	✓	✓	
	Hero 6	✓	✓	
	Max 360 Action Camera	✓	✓	
<b>DJI</b>	Pocket 2	✓	✓	
	Osmo Action 4K	✓	✓	
	Osmo Pocket Gimbal	✓	✓	
	Action 2	✓	✓	
<b>Sony</b>	Cyber-shot DSC-RX0 II	✓	✓	
	RX0 ultra-compact	✓	✓	
	DSC-HX99	✓	✓	
	DSC-WX800	✓	✓	
	FDR-X3000	✓	✓	
	HDR-AS300	✓	✓	
<b>Insta360</b>	ONE X2	✓	✓	
	ONE R	✓	✓	
	GO	✓	✓	

Brand	Model	1066x microSD	633x microSD	PLAY microSD
<b>Polaroid</b>	CUBE Act Two	✓	✓	
<b>Mevo</b>	Plus Live Streaming	✓	✓	
	Start Live Streaming	✓	✓	
<b>Kodak</b>	PIXPRO SP360	✓	✓	
<b>Garmin</b>	VIRB Ultra	✓	✓	

## Drones

Brand	Model	1066x microSD	633x microSD (128GB above)	PLAY microSD
<b>DJI</b>	Mavic 3	✓	✓	
	Mavic Air 2	✓	✓	
	Mavic Mini	✓	✓	
	Mavic 2 Pro	✓	✓	
	Mavic 2	✓	✓	
	Mavic Pro	✓	✓	
	Phantom 4 Pro 2.0	✓	✓	
	Phantom 4 Pro	✓	✓	
	Phantom 4	✓	✓	
	Inspire 2	✓	✓	
<b>Autel Robotics</b>	EVO II PRO 6K	✓	✓	
<b>Snapstain</b>	SP510 2.7K	✓	✓	
<b>Fimi</b>	X8SE 2020 4K	✓	✓	
<b>Parrot Anafi</b>	4K Portable Drone	✓	✓	
<b>Power Vision</b>	PowerEgg	✓	✓	

## Video Games Consoles

Brand	Model	1066x microSD	633x microSD (128GB above)	PLAY microSD
<b>Nintendo</b>	Switch	✓	✓	✓
	Switch Lite	✓	✓	✓

### Rigorously tested

All Lexar product designs undergo extensive testing in the Lexar Quality Labs, facilities with more than 1,100 digital devices, to ensure performance, quality, compatibility, and reliability.

All Lexar memory cards have been tested under a variety of tough conditions. These cards are proved to be waterproof, temperature-proof and shockproof.

For additional information on product, warranty or return information go to [www.lexar.com/support](http://www.lexar.com/support)

