



To Open the Lock the First Time:

SET the combination to L-O-C-K. DEPRESS shackle and PULL open.

To Set Your Own Combination:

(REMEMBER: Combination can only be set when lock is open.)

1. INSERT 'reset' tool (enclosed in package) in hole on side of lock.
2. PUSH key in and TURN key 90° in either direction (key automatically stays in this position). Failure to exert force while pushing key in will result in a failed attempt to set or reset combination.
3. SET wheels to desired combination.
4. TURN and remove reset tool. Lock is now set to new combination.

BE SURE TO RECORD YOUR COMBINATION.

To Lock: SCRAMBLE the wheels and CLOSE the shackle.

To Reopen: DIAL your combination and DEPRESS shackle.

Pour l'ouverture initiale du cadenas:

Réglez la combinaison à L-O-C-K. Appuyez sur l'arceau puis tirez.

Pour entrer votre propre combinaison:

(RAPPEL: La combinaison ne peut être réglée que lorsque le cadenas est ouvert.)

1. Introduisez l'outil de codage (fourni dans l'emballage), dans le trou sur le côté du cadenas.
2. Introduisez la clé et tournez-la de 90°, dans une ou l'autre direction (la clé demeure automatiquement en position). À défaut d'exercer une pression en insérant la clé, il sera impossible de régler la combinaison.

3. Entrez la combinaison désirée en positionnant les molettes.

4. Tournez et retirez l'outil de codage. Le cadenas a maintenant une nouvelle combinaison.

PRENEZ NOTE DE VOTRE COMBINAISON.

Pour verrouiller: Bougez les molettes et fermez l'arceau.

Pour rouvrir: Entrez votre combinaison personnelle et appuyez sur l'arceau.

Para abrir candado por primera vez:

Poner combinación en L-O-C-K. Bajar gancho y abrir halando.

Para crear su propia combinación: (Recuerde: Sólo se puede crear combinación con el candado abierto.)

1. Inserte llave para cambiar (incluída en el empaque) en hueco al costado del candado.
2. Introduzca la llave y gírela 90° en cualquier dirección (llave permanece en esta posición automáticamente). Es importante ejercer presión a la misma vez que se introduce la llave. De no hacerlo, no podrá fijar su combinación o crear una nueva.
3. Coloque las ruedas a la combinación deseada.
4. Dele vuelta y retire llave. Candado tiene ahora una nueva combinación.

RECUERDE REGISTRAR SU COMBINACIÓN.

Para cerrar: Gire libremente las ruedas y cierre el gancho.

Para reabrir: Marque su número combinación y empuje el gancho.

Choose from these possible combinations or create your own:
Choisissez l'une de ces combinaisons ou créez la vôtre:
Elija de estas posibles combinaciones o cree la suya propia:

WORDS MOTS PALABRAS

BALD	BORN	DOCK	LEAN	MART	MOTH	PAST	PORE	RISK	SURE
BALL	BRAN	DONE	LEEK	MASH	MUCH	PATH	PORK	SACK	TACK
BANK	BRAT	DOTE	LENT	MASK	MULE	PATS	PORT	SALE	TACT
BARE	BUCK	DOTS	LESS	MASS	MUSE	PEAK	POSE	SALT	TALK
BARK	BUDS	DUCK	LIAR	MAST	MUSH	PEAR	POSH	SANE	TALL
BARN	BULK	DUDE	LICK	MATE	MUSK	PECK	POST	SAND	TANK
BASE	BULL	DUET	LIES	MATH	MUTE	PEEK	POTS	SANK	TASK
BASH	BUNK	DULL	LINE	MEAL	MUTT	PEER	PRAY	SASS	TEAR
BATH	BUNS	DUNE	LINK	MEAN	MYTH	PELT	PREY	SEAL	TEEN
BATS	BURN	DUNK	LINT	MEAT	NEAT	PENS	PUCK	SEEK	TENT
BEAD	BURR	JARS	LION	MELD	NECK	PERK	PUNS	SHED	TEST
BEAK	BURY	JEST	LOAN	MELT	NEED	PEST	PUNT	SHOT	TICK
BEAN	BUSH	JETS	LOCK	MEND	NEST	PETS	PURE	SICK	TILE
BEAR	BYTE	JILT	LONE	MESH	NETS	PICK	PUSH	SIDE	TILT
BEER	DADS	JOCK	LOOK	MESS	NICE	PIES	RACE	SILK	TINT
BEET	DARE	JOLT	LORD	MICE	NINE	PILE	RACK	SINK	TINY
BELT	DARK	JUNK	LORE	MILE	NONE	PINE	RANK	SIRS	TIRE
BEND	DART	JUST	LOST	MILK	NOOK	PINK	RANT	SLAY	TOES
BEST	DASH	JUTE	LUCK	MINE	NOON	PINT	RARE	SLED	TOLL
BETS	DATE	LACE	LURE	MINK	NOSE	PITS	RASH	SLOT	TONE
BIRD	DEAR	LACK	LURK	MINT	NOTE	PITY	RATS	SOAR	TONS
BITE	DENT	LADS	LUSH	MIRE	NUNS	PLAN	READ	SOCK	TOOT
BOAT	DIAL	LADY	LUST	MISS	NUTS	PLAY	REAL	SOLD	TOSS
BOLD	DICE	LARD	MACE	MIST	PACE	PLOT	REED	SOLE	TOTE
BOLT	DIET	LARK	MALE	MOAT	PACK	PLOY	REEL	SOOT	TOTS
BOND	DILL	LASH	MALL	MOCK	PACT	PODS	RENT	SORE	TRAY
BONE	DINE	LAST	MALT	MOLE	PARE	POET	REST	STAR	TREK
BOOK	DIRT	LATE	MANE	MONK	PARK	POLE	RIDE	STAY	TROT
BOOT	DISH	LEAD	MARE	MOON	PART	POLL	RINK	SULK	TUCK
BORE	DISK	LEAK	MARS	MORE	PASS	POND	RIOT	SUNK	TURN

NAMES NOMS NOMBRES

BART	BRET	DYAN	JETT	JOSH	LACY	MARY	NILS	SETH	TORY
BERT	BURT	JACK	JOAN	JOSS	LEAH	MATT	NOAH	STAN	TREY
BESS	DICK	JADE	JODY	JUDE	LYLE	MICK	RICH	TATE	TROY
BETH	DION	JANE	JOEL	JUDY	MACK	MORT	RICK	TESS	TYNE
BILL	DIRK	JEAN	JOEY	JULS	MADY	NATE	RYAN	TISH	
BRAD	DORY	JESS	JORY	JUNE	MARK	NICK	SEAN	TONY	

