Hello ,

Thank you for purchasing the LEMEGA PR1 Pocket DAB Radio and we apologize for not clearly describing the preset button.

To store preset

Press and hold the preset buttons until the display shows a list of the Preset stores numbered 1 to 10 these are displayed as either ‘Empty’ or with the currently stored station name. Use the ‘Navigation’ dial to choose a preset memory then press ‘Select’ to store the currently-playing station. After confirming the preset station is stored the display reverts to the Now playing screen.

To recall preset

Press preset button , The display will show a list of the presets stored number 1-10.
Use the ‘Navigation’ dial to choose a preset and press ‘Select’ to play that station.
If you have any other questions, please let us know and we will try our best to help you.
Your understanding and support will be greatly appreciated.

Have a good day.
Best regards,
LEMEGA TEAM
info@lemegaaudio.com

Operation Video