Redsack

Smart quantitative wine dispenser

WP-007

Adapter Replacement Manual

01
STEP

Rotate counterclockwise to remove bottom cover

02
STEP

Take out the adapter

03
STEP

Replace with a suitable adapter

04
STEP

Rotate clockwise to install bottom cover

05 STEP

Adapter replacement complete