

# Can I download new apps to the My Apps area of the Blu-ray Disc Player?

Each Blu-ray Disc Player has a set amount of pre-installed applications. It is not possible to download new applications to your Blu-Ray Disc player.

You can add or remove these pre-installed apps from the **My Apps** area of the Blu-ray Disc Player.

To add your favourite apps to the **My Apps** area, follow any of the methods below.

## Method 1

1. While in the **My Apps** screen, press the **UP ARROW** or **DOWN ARROW** button on the supplied IR remote control to select the **Plus (+)** sign.
2. In the **All Apps** screen, select the app you want to add.
3. Press the **ENTER** button.

## Method 2

1. On the supplied IR remote control, press the **HOME** button.
2. Select the **All Apps**.
3. Press the **ENTER** button.
4. In the **All Apps** screen, select the app you want to add.
5. Press the **OPTIONS** button.
6. Select **Add to My Apps**.

To remove apps from the **My Apps** area, follow these steps:

1. On the supplied IR remote control, press the **OPTIONS** button.
2. In the **My Apps** area, select **Remove Application** to remove the app.

# What kind of devices can be connected to the mobile projector and Blu-ray Disc Player when using the Screen mirroring function?

The mobile projector and Blu-ray Disc Player can be connected to a Screen mirroring compatible device such as a Xperia mobile device. The Screen mirroring feature is using the Miracast technology, so it is now possible to connect your mobile device to the mobile projector and Blu-ray Disc Player using the Screen mirroring feature.

# No sound is heard when using the HDMI connection from the Blu-ray Disc player.

Check the settings of **HDMI Audio Output** in **System Settings**.

- When **HDMI Audio Output** is set to **HDMI2**, check the connection of the HDMI OUT 2 jack on the Blu-ray Disc player and make sure that the connected device is turned on.
- To output sound from a TV, connect the TV to the HDMI OUT 1 jack of the Blu-ray Disc player and change the **HDMI Audio Output** setting to **Auto** or **HDMI1**.

## NOTE:

- The HDMI OUT 2 jack on the Blu-ray Disc player outputs audio only. When you want to output both video and audio from the device that is connected to the Blu-ray Disc player, connect the device to the HDMI OUT 1 jack on the Blu-ray Disc player.
- If there is no sound output from the TV even though you have checked the methods above, refer to [There is no sound or audio when connecting Blu-ray Disc player to TV when using an HDMI connection.](#)