


If you find that the power supply cannot be set below 5V, please help to adjust it according to the following operation, thank you.

1. Stop working and Power off , firstly Open the power supply .



2. Pull out the plug, The connectors of A and C are reversed. Use a similar tool to pry the connector out, original the position is ABC ,but correct is CBA.



3. when finish it , Please connect the wire back, then power ON, try it again you can use it below 5V.



At the end , In order to make it easier for you to understand this operation, we would like to share the video on YouTube. Address at below :

<https://www.youtube.com/watch?v=jpvXrKTrmJg>