

## SAVE THESE IMPORTANT SAFETY INSTRUCTIONS

Please read all instructions before using this appliance.

These instructions are also available on our website.  
Please visit [www.hot-europe.com](http://www.hot-europe.com)



**WARNING:** Do not use this appliance near bathtubs, showers, basins or other vessels containing water.

**WARNING:** This appliance must not be taken into the bathroom.

This appliance can be used by children aged from 8 years and above, and by persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.

Children shall not play with the appliance.

Cleaning and user maintenance shall not be made by children without supervision.

If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.

**WARNING:** Do not leave the appliance unattended. Do not allow bare skin or the eyes to come into contact with any heated surface on the appliance when in use. Do not place the appliance on any heat-sensitive surfaces when hot or plugged into the mains. Always unplug the appliance when not in use.

**WARNING:** Do not use this appliance on synthetic hair or wigs.

**NOTE:** Use on dry hair only.

**WARNING:** Should this product malfunction, do not attempt to repair it. This appliance has no user-serviceable parts or components.

This product carries the CE mark and is manufactured in conformity with the Electromagnetic Directive 2004/108/EC, the Low Voltage Directive 2006/95/EC, and the ROHS Directive 2011/65/EU.

## OTHER PRODUCTS IN THE TONI&GUY SALON PROFESSIONAL COLLECTION

### COMPACT AC POWER DRYER



### FLAWLESS FINISH STRAIGHTENER



### CREATIVE SLIM DEFINER



### EXTREME VOLUME ROLLERS



This appliance complies with EU legislation 2012/19/EU on end of life recycling. Products showing the 'Crossed Through' wheeled bin symbol on either the rating label, gift box or instructions must be recycled separately from household waste at the end of their useful life.

Please DO NOT dispose of appliance in normal household waste. Your local appliance retailer may operate a 'take-back' scheme when you are ready to purchase a replacement product, alternatively contact your local government authority for further help and advice on where to take your appliance for recycling.

220-240V ~ 50 - 60 Hz 145W

TONI&GUY appliances by Helen of Troy Limited.

TONI&GUY and related logos are used under licence from Unilever PLC.

© 2015 Helen of Troy (AW006545).

AW ISSUE No#:3 Date: 071715



# TONI&GUY

## SALON PROFESSIONAL



# DEEP BARREL

## WAVER

Use & Care Instruction Manual  
TGIR1928UK

## OPERATING INSTRUCTIONS

This appliance is intended for household use only.  
The appearance of this appliance may differ from the illustration.

### CERAMIC TOURMALINE TECHNOLOGY

Ceramic Tourmaline is professionally preferred for its high heat that preserves hair's natural moisture for styles without frizz. The easy-to-clean plates emit high, constant heat to penetrate hair follicles quickly and retain natural moisture while minimising damage for soft, luxurious styles.

### HEATING THE APPLIANCE

Plug the appliance into the mains. To switch the appliance on, slide the On/Off switch to the (I) position and rotate the Temperature Control dial to the number that corresponds to the heating level desired. Allow the appliance a few minutes to heat up. Do not, under any circumstances, leave the appliance unattended when switched on. To turn the appliance off, slide the On/Off switch to the (O) position and unplug the appliance.

For first use it is recommended that you start with the lowest heat setting and gradually increase temperature to find a suitable level. Only use as much heat as you need for effective styling. Fine hair will require a low heat setting and thicker, less manageable hair will usually require a medium-high heat setting.

### LOCKING MECHANISM

This appliance has a lock mode which ensures that the product remains in a closed position when placed down. The appliance can be locked by sliding the locking mechanism towards the cord. To unlock the appliance slide the locking mechanism towards the plates.

### STYLING

Separate a two-inch section of hair, gently place the hair between the hot plates and clamp down firmly on the handle.

Hold for 5 to 8 seconds for fine hair and 10 to 15 seconds for thick hair (the ends will probably require less heat than hair that grows closer to the root). Carefully release the pressure on the handle and allow the hair to gently slide away from the plates. The waving process requires some overlapping; match the lower wave of the hair with the upper edge of the plates each time. For best results work from the root towards the ends of the hair.

Allow hair to cool. Do not comb or brush the hair as this will undo the style.

### CLEANING

Always unplug the appliance from the mains after use and allow it to cool before cleaning. To clean, wipe the waver and plates with a damp cloth. Ensure the appliance is completely dry before use and that heated surfaces on the unit are free of dust, dirt, styling sprays and gels.

### STORAGE

Always unplug when not in use.

Allow the appliance to cool before storing. Always store in a dry location. Do not pull or twist the cord. Do not wrap the cord around the appliance, as this may cause the cord to wear prematurely and break. Regularly check the power cord for wear and damage (particularly where it enters the appliance and the plug).



### GUARANTEE AND SERVICE SECTION:

Your TONI&GUY appliance is guaranteed against defects under normal use for five years from the original date of purchase. If your product does not perform satisfactorily because of defects in materials or manufacture, within the warranty period, it will be replaced. Please retain your receipt or other proof of purchase for all claims within the warranty period. The guarantee becomes void if the proof of purchase is not presented. For all claims within the warranty period please contact our Support Team.

This guarantee does not cover defects which have occurred due to misuse, abuse, or are caused by failure to follow the instructions contained within this manual.

This does not affect your consumer statutory rights.

The manufacturing date is given by the 4 digit Batch Number marked on the rear of the product. The first 2 digits represent the week of manufacture, and the last 2 digits represent the year of manufacture. Example: 3415 - product manufactured week 34 of the year 2015.

For product support, please visit us at: [www.hot-europe.com/support](http://www.hot-europe.com/support)

Or contact us by phone: +44 (0) 115 965 7430

For product information, visit us at: [www.toniandguyelectrical.com](http://www.toniandguyelectrical.com)  
& [www.hairmeetwardrobe.com](http://www.hairmeetwardrobe.com)

### TOURMALINE

A naturally ionic crushed gemstone. The negative ions produced by this Tourmaline hair appliance help to protect your hair when styling, nourishing and conditioning hair allowing for a super smooth and shiny finish. Tourmaline helps prevent colour loss and maintain core colour intensity.