

INSTRUCTIONS FOR USE

- Place the appliance on a level, heatproof surface. Do not open the lid at this time.
- Turn the appliance on by sliding the switch to the heat setting suitable for your hair type.
- For best results, allow the rollers to heat up for 10 minutes.
- One roller has a 'heat ready dot' on top. The dot will turn from red to white, indicating optimum temperature has been reached and the rollers are ready to use. Open the lid and begin to style the hair.
- Comb through the hair to remove any tangles. Divide in to sections and select a roller. The rollers can be used on damp or dry hair.
- Begin placing the rollers at the top of the head and work down towards the nape of the neck.
- Take a section of hair the width of a roller, starting at the hair ends wind the hair around the roller, holding the hair taut. Keep the roller at right angles to the scalp, to ensure even curls.
- Secure the roller with one of the clips or metal pins provided. If using the metal pins, insert the pin over the roller, through the hair and away from you.
- Repeat throughout each section until you have used all the rollers.
- To turn off the appliance by sliding the switch back to the '0' position and unplug the appliance.
- Once the rollers have cooled, remove the rollers from the hair. Gently hold the roller in one hand and remove the clip or metal pin with the other. Slowly unroll the roller, being careful not to pull the hair as you unwind. Once the hair is loose from the roller, let it bounce back up.
- Let the hair fully cool so the curl can 'set', then style the hair as desired.
- Once the appliance has cooled down, replace all the clips and rollers back in the unit and close the lid.
- Allow the appliance to cool before storing away.

IMPORTANT!

- The BaByliss Thermo-Ceramic Rollers have been specifically designed to reach very high temperatures in order to produce fast and perfect curl formation.
- When applying the rollers to short or fine hair, allow the rollers to heat up until the heat ready dot turns white. Once the heat ready dot has turned white, turn off the unit and open the lid. Allow the rollers to cool until they feel comfortable to touch when applying into the hair. Failure to do so may lead to discomfort.
- Always take extra care to avoid the rollers coming into direct contact with the scalp.

Heat Settings

There are 2 heat settings to choose from. Slide the 'on/off' switch to the first position for the low heat 'I' and the second position to select high heat 'II'. If you have delicate, fine, bleached or coloured hair, use the lower heat settings. For thicker hair, use the higher heat settings.