



Function

This instrument has a switch button on the back, short press to switch the ODOTRIP clock


1. On the ODO interface, long-press the on button to switch MILE&MPH and KM&KM/H;
2. Long press the on/off key on TRIP interface to clear subtotal mileage;
3. Long press the on button on the clock interface, and the hour adjustment starts to blink. Short press +1; Long press the on key again, and the minute setting will start to blink. Short press +1 and then long press the on key to exit to the main page, or exit automatically after 5 seconds, and the parameters will be saved automatically (system setting, contact after-sales service).



| | |
|-----------|----------------|
| Terminal | DJ611-2.8x0.5 |
| Connector | DJ7091A-2.8-21 |



| | |
|-----------|----------------|
| Terminal | DJ611-2.8x0.5 |
| Connector | DJ7091A-2.8-21 |



| | |
|-----------|----------------|
| Terminal | DJ611-2.8x0.5 |
| Connector | DJ7031A-2.8-21 |



Green&Black
Near light