


Measuring Guide


Furniture Sizes



Chair (seats 1)
*outside arm to
outside arm -*
32 in. to 43 in.



Loveseat (seats 2)
*outside arm to
outside arm -*
58 in. to 73 in.



Sofa (seats 3 or more)
*outside arm to
outside arm -*
74 in. to 96 in.

Seat cushion styles

Box Cushion

One, two and three piece
slipcovers in form fit
and relaxed fit fabrics.





T- Cushion

One, two and three piece
slipcovers in form fit
and relaxed fit fabrics.



Form Fit and Relaxed Fit Arm Width Guidelines




Form Fit and Relaxed Fit Seat Width Guidelines

Chair - 24"
Loveseat - 50"
Petite Sofa - 60"
Sofa - 72"




Chair - 35"
Loveseat - 65"
Sofa - 84"




Wing Recliners and Wing Chairs

Form Fit Box Cushion
Wing Recliner
Seat Width - 24"
Back Height - 45"


Fits both box cushion
and wing recliners



Form Fit T-Cushion
Seat Width - 32"
Back Height - 45"




Relaxed Fit
T-Cushion
Seat Width - 29"
Back Height - 42"




Recliners and Lift Recliners

Sure Fit Form Fit
78" to 88"



Medium Sure Fit
Form Fit
68" to 78"

Large Sure Fit
Form Fit
78" to 92"



Ottomans



Form Fit - 30"
Measure the longest
side of ottoman


Relaxed Fit -
up to 116"
Measure all 4 sides
and add together

Furniture Covers

Standard Covers

Seat
Widths

Chair 24"
Loveseat 48"
Sofa 70"




Back Lengths
39" or 46"

Deluxe Covers

Seat
Widths

Chair 26"
Loveseat 52"
Sofa 76"



Back Length 50"
(longer arm length)

Chaise Covers

Seat
Width - 34"
Seat
Depth - 65"



Dining and Folding Chairs



Short Dining
Chair Cover
Back Height
up to - 42"
Seat Width - 18.5"



Long Dining
Chair Cover
Back Height
up to - 42"
Seat Width - 18.5"



Folding
Chair Cover
Back Height
up to - 32"
Seat Width -
15" square