

Steps to troubleshoot flickering:

1. Reduce the Refresh Rate to try to remove the flickering (enter On-screen Display (OSD) Menu -> Select "Game" -> Select "Overclock Refresh Rate." Press the down arrow to reduce refresh rate)
2. Disable Overclocking (enter OSD Menu -> Select "Game" -> Select "Overclock" -> Switch from "On" to "Off")
3. Swap video cable with a known good to see if issue is resolved
4. Update graphics card driver and firmware
5. Remove other devices plugged into same power strip to check for electromagnetic interference