

WARRANTY NOTICES AND DISCLAIMERS: Splash Resistant* / Dust Resistant:

SPLASH RESISTANT is a term used to describe an extra level of protection this device offers against accidental exposure to a minimal amount of moisture, water or dust. Splash Resistant does not guarantee that damage will not occur if this device is subjected to direct contact with water. MINIMIZING DAMAGE: In order to minimize the possibility of damage, please be sure the following precautions are taken: (A) The Splash Resistant feature only works in conjunction with the cameras, lenses, and accessories that carry the same Panasonic Splash Resistant certification. (B) The device is not designed to be Dust and Splash Resistant when or if a USB connection cable or the cable holder is attached to it. (C) Make sure that all doors, socket caps and terminal covers are securely closed. (D) Make sure that you are in a dry and secure place when changing the battery, lens or memory card, or other accessory. After changing, make sure their protective doors are securely closed. (E) If this device is exposed to water, sand or any other foreign material clean it as soon as possible, taking the necessary precautions that the foreign substance does not get inside the device. CAMERA MONITOR CLEANING: If sand, dust, or liquids such as water droplets adhere to the monitor, wipe them off with a dry soft cloth. (A) Not doing so may cause the monitor to respond incorrectly to touch operations. (C) If the monitor is closed when such liquids are present, malfunction may result. COLD TEMPERATURES: When using in cold temperatures (10C to 0C (14 F to 32 F): Attach a Panasonic interchangeable lens with a minimum recommended operating temperature of 10 C (14 F) before use. CAUTIONS: Do not place your hands inside the camera mount of the digital camera body. Since the sensor unit is a precision apparatus, it may cause a malfunction or damage.