

Cell Phone Tripod Adapter Instructions

Your tripod head attaches and releases with the lever on the tripod and the backside will have a flathead screw that you tighten from the underside. (The extra 1/4 tripod screw has been included as a bonus with the adapter you purchased, and you will need to remove/unscrew it before attaching the adapter to your tripod). Tripod is not included in this purchase.

To attach it to the cell phone tripod adapter, use the release lever on the tripod itself that will allow you to remove the tripod head that has the screw. Once you do this, tighten the screw on to the cell phone tripod adapter threads.

Reattach the tripod head to the tripod with the cell phone adapter now attached by the screw. The adapter is spring-loaded, so you can pull it open some (by pulling the rubber piece on top) to insert your cell phone. Release the rubber grip piece. The adapter will put enough pressure on the phone from the spring action to hold the cell phone in place on the tripod.



Attaches to any tripod with a standard screw 1/4"



Troubleshooting:

If the cell phone tripod adapter arrived broken, or will not thread onto your tripod head, please let us know by clicking on “Contact Seller” button in your order history by this product, or by the seller DaVoice in the product listing, then you will see the “Have a Question for DaVoice? Ask a question” button and we can send you a replacement free of charge, or use the link below:

https://amazon.com/gp/help/contact-seller/contact-seller.html?sellerID=A11M4MGZGGFZHT&marketplaceID=ATVPDKIKX0DER&ref_=v_sp_contact_seller

Please include your order number so we can pull your information.