
COMPACT
AIR PURIFIER

home™
homelabs.com



Before using your Compact Air Purifier, please read this manual.

TABLE OF CONTENTS

Safety Precautions	5
Get to Know Your Appliance	6
How to Use Your Appliance	7
Cleaning and Maintenance	8
Troubleshooting	9
Warranty	10
Manufacturing Info	10
Warning	11
Contact Us	11

Safety Precautions

SAVE THESE INSTRUCTIONS / For Household Use Only


When using your hOme™ Compact Air Purifier (appliance), basic safety precautions should always be followed to reduce the risk of fire, electric shock, and/ or injury to person. Incorrect operation due to ignoring instructions may cause harm or damage.

- All safety messages will tell you what the potential hazard is, how to reduce the chance of injury, and tell you what can happen if the instructions are not followed.
- Read all instructions before using the appliance.
- Do not operate this or any other appliance with a damaged cord.
- If the cord is damaged, contact hOme™ customer service at 1.800.898.3002 to avoid a hazard.
- The appliance must be positioned so that the plug is accessible.
- Connect plug to properly polarized outlets only. No other appliance should be plugged into the same outlet. Be sure that the plug is fully inserted into the receptacle.
- Do not run the power cord over carpeting or other heat insulators. Do not cover the cord. Keep the cord away from traffic areas, and do not submerge in water or any other liquid.
- We do not recommend the use of an extension cord, as it may overheat and become a risk of fire.
- Never use the power cord to pick up, carry, drag, pull, or lift the appliance. Do not pull the cord against or around sharp corners and edges. This could result in injury to the user or damage to the cord.
- Unplug the appliance before cleaning or making any repairs or servicing.
- Exercise caution and use reasonable supervision when appliance is used near children.
- Do not clean your appliance with flammable fluids. The fumes can create a fire hazard or explosion.
- Do not operate the appliance in any greasy environment, such as in the kitchen. This appliance is not intended to filter oil or grease from the air.
- Do not tip over your appliance.
- Do not use the appliance in bathrooms or other humid environments.
- Use care when operating the appliance by keeping all foreign objects, fingers, body parts, hair, loose clothing and jewelry away from openings.
- Do not use the appliance near fireplaces or in areas where flammable or combustible vapors or appliances may exist.
- This appliance operates at 100-240V, 50/60Hz only.
- To reduce the risk of fire or electric shock, do not use this appliance with any solid-state speed control devices.

⚠ WARNING

The appliance must be placed on a flat firm surface.

Get to Know Your Appliance



Get to Know Your Appliance

SPECIFICATIONS

- **Input Voltage:** AC100~240V
- **Frequency:** 50~60Hz
- **Output Voltage:** DC12V
- **Rated Power:** 4W
- **Coverage Area:** 40 sq.ft. (3.75 sq. meters)
- **Appliance Size:** 6.7 in x 6.7 in x 8 in (170mm X 170mm X 205mm)
- **Appliance Weight:** 2.4 lbs (1.1 kg)

How to Use Your Appliance

1. **Connect the power supply**
   Insert the output end of supplied adapter into the connector on the bottom of the appliance (see Figure 1). Make sure the filter and the bottom cap are fully assembled, then put the appliance on a flat surface. After that, plug the adapter into a power outlet.

WARNING
To ensure safe operation of the appliance, always use the supplied adapter to avoid any accident or injury. If the supplied adapter is damaged or lost, please contact

2. **Turn on/off and settings**
   Once the appliance is plugged in, the LED indicator light around the power button will turn red indicating you are in “standby” mode.
   Press the “power button” to turn the appliance to low speed (the indicator LED surrounding the power button will turn light blue in color).
   Press the “power button” again to turn the appliance to high speed (the indicator LED surrounding the power button will turn dark blue in color).
   Press the power button again to turn the appliance off.

WARNING
If the appliance is not being used, please turn off the appliance and unplug it from the power outlet to avoid damage.

3. **Ion function**
   The ion generator inside the appliance provides millions of ions and turns on automatically when the appliance is on. The ion generator turns off when the appliance is on “standby” mode or turned off.

4. **Change Filter Indicator**
   The “change filter” indicator light will flash each time the filter needs to be replaced.

Cleaning and Maintenance

WARNING
Always make sure the appliance is turned off and unplugged before cleaning.
Follow the steps below to change the filter in your appliance:


You can use vacuum cleaner to clean the surface of filter every 4 weeks use to extend the life time of filter. More frequent cleaning will be necessary if the unit is located in an area with a high level of airborne contaminants (excessive amounts of smoke, pet dander, etc.).

We suggest to replace the filter at least 6 months of use or replace once the reminding indicator on the top panel is flashing to keep the efficient working of the air purifier.

Exposing the air purifier to candle/oil/fireplace soot and smoke is not recommended and will require more frequent cleaning.

ATTENTION: Do not use water or any household cleaners or detergents to clean the Filter.


1. Clean the filter
   - Rotate the bottom cap anticlockwise to the opening and take detach the bottom cap (see picture 1).
   - Take out the Filter according to the direction as picture 2 and picture 3.
   - To clean the Filter, use the brush or crevice attachment with a vacuum cleaner. Run the attachment along the inlet and outlet side of the filter, cleaning between the crevices as much as possible. Do not use water or any household cleaners or detergents to clean the Filter.
   - Once the Filter has been cleaned and checked for any possible damage, replace the filter back in the reverse direction described here. And rotate it clockwise till you can hear a click, the cap is closed.




2. Change the Filter
   - Rotate the bottom cap anticlockwise to the opening and detach the bottom cap (see picture 1).
   - Take out the used Filter. Change to new filter and insert into the air purifier according to the direction as picture 2.
   - Cover the cap and rotate it clockwise till you can hear a click, and the cap is closed.
   - Use toothpick or something similar to press the “filter changing indicator” for 3 seconds, the indicator will flash 3 times and the buzzer will sound 3 times, which means the filter reset successfully. The air purifier can be operated normally after plugging in.

3. Clean the surface of housing
   - Turn off the air purifier and unplug the adaptor.
   - Use soft cloth with little soap water to clean the surface of housing.
   - Please make sure the water would not flow into the air purifier, otherwise it may damage your air purifier and lead to electric shock and injury.
   - Place the air purifier somewhere well ventilated. Never expose to the sun directly. Only turn on the air purifier when it is thoroughly dry.


Picture 1



Picture 2



Picture 3



Troubleshooting

PROBLEM	POSSIBLE CAUSE	SOLUTION
The LED indicator light does not turn red to show standby mode after the appliance is plugged in.	The adapter is not properly connected to the appliance.	Check if the adapter power cable is correctly inserted into the bottom of the appliance.
	The adapter is damaged.	Contact hOme™ customer service at 1-800-898-3002 to get a replacement adapter.
On switching to the high mode setting, the airflow does not increase OR there is no airflow at all.	The outlet airflow is being blocked by something.	Clear the outlet of anything blocking it and wipe the outside surface with a soft dry cloth.
	Damage may have incurred within the appliance.	Contact the hOme™ customer service to repair or replace the appliance at 1-800-898-3002.

Warranty

hOme™ offers a limited two-year warranty (“warranty period”) on all of our products purchased new and unused from hOme Technologies, LLC or an authorized reseller, with an original proof of purchase and where a defect has arisen, wholly or substantially, as a result of faulty manufacture, parts or workmanship during the warranty period. The warranty does not apply where damage is caused by other factors, including without limitation: (a) normal wear and tear; (b) abuse, mishandling, accident, or failure to follow operating instructions; (c) exposure to liquid or infiltration of foreign particles; (d) servicing or modifications of the product other than by hOme™; (e) commercial or non-household use.

The hOme™ warranty covers all costs related to restoring the proven defective product through repair or replacement of any defective part and necessary labor so that it conforms to its original specifications. A replacement product may be provided instead of repairing a defective product. hOme™’s exclusive obligation under this warranty is limited to such repair or replacement.

A receipt indicating the purchase date is required for any claim, so please keep all receipts in a safe place. We recommend that you register your product on our website, homelabs.com/reg. Although greatly appreciated, the product registration is not required to activate any warranty and product registration does not eliminate the need for the original proof of purchase.

The warranty becomes void if attempts at repair are made by non-authorized third parties and/or if spare parts, other than those provided by hOme™, are used.

You may also arrange for service after the warranty expires at an additional cost.

These are our general terms for warranty service, but we always urge our customers to reach out to us with any issue, regardless of warranty terms. If you have an issue with a hOme™ product, please contact us at 1-800-898-3002, and we will do our best to resolve it for you.

This warranty gives you specific legal rights, and you may have other legal rights which vary from state to state, country to country or province to province. The customer may assert any such rights at their sole discretion.

Manufacturing Info

This manual is to be used with all items with the model number

HME020020N

SKU# : HME020020N
PART#: HME020020MNL

RATING: 50~60Hz, AC100~240V, AC ONLY
3M/ cu cm negative ions released

Warning

Keep all plastic bags away from children.

State of California Proposition 65 Warnings:

THIS PRODUCT COULD CONTAINS ONE OR MORE CHEMICALS WHICH ARE KNOWN TO THE STATE OF CALIFORNIA TO CAUSE CANCER, BIRTH DEFECTS OR OTHER REPRODUCTIVE HARM.

Manufacturer, distributor, importer and seller are not liable for ANY damage caused by improper use, storage, care or failure to follow warnings associated with this product.

Contact Us

CHAT WITH US | CALL US | EMAIL US

homelabs.com/chat | **1-(800)-898-3002** | **help@homelabs.com**



For Household Use Only

1-800-898-3002
help@homelabs.com
homelabs.com/help

© 2016 hOme Technologies, LLC
37 East 18 Street, 7th Floor
New York, NY 10003

All rights reserved. hOme™. Printed in China.