


USER MANUAL

Please read the user manual carefully before using the product.




1

Indicator Lights

1. When wireless charger is connected to power source first time, all indicators will light on for 3s. Then the indicator will light off.
2. Blue lights on means the device is charging normally.
3. When the wireless charger attach the foreign objects, the indicators will flash blue light. (Except for the watch indicator)
EX: When the cellphone indicator flashes blue light, there are some foreign objects on the surface of the cellphone charging pad.
4. The blue light flashes, indicating abnormal charging. (Except for the watch indicator)
5. When the blue light flashes, the device wasn't placed on the right charging place.

2

Compatible Sheet



For iPhone

iPhone 14, iPhone 14 Plus, iPhone 14 Pro, iPhone 14 Pro Max, iPhone 13 mini, iPhone 13, iPhone 13 Pro, iPhone 13 Pro Max, iPhone 12 mini, iPhone 12, iPhone 12 Pro, iPhone 12 Pro Max (Compatible with official MagSafe cases)

For Earbuds


AirPods Pro (2nd generation), AirPods Pro, AirPods Pro with MagSafe, AirPods (3rd generation), Airpods 2 (Must place on the right place)

For Apple Watch

Apple Watch Ultra/8/7/6/5/4/3/2/SE

3

Folding Method



4

Product Specification

Model: W313
Input: 5V/3A 9V/2A (18W-40W)
Output: Up to 2.5W For Watch Up to 3W For Earbuds Up to 10W For Cellphone
Adapter: Suitable for 18-40W adapter

Package Contents

- 1 X Wireless Charger
- 1 X 18W Adapter
- 1 X User Manual
- 1 X USB-A to USB-C Charging Cable

Reminder

1. Make sure your devices support wireless charging before using.
2. It is recommended to use the original charging cable and adapter.
3. Please remove the cellphone/earbuds case before charging.
4. Don't use or place the product at high temperature or expose direct to the sun.
5. Don't immerse the product in water or near ignition sources.
6. When the function temperature exceeds 104 °F, the charging will be interrupted to avoid damage to the cellphone/watch/earbuds battery.
7. AirPods 2nd has two different versions of charging cases. A1938 supports wireless and wired charging. A1602 wired charging only.

6

FAQ

- Q1:** How do wireless charging speeds compare to a traditional wired charger?
A1: It depends on your device, adapter, and wireless charger. It is recommended to use the 18-40W adapter for the product. Once the wireless charger's input is lower than 5V/3A 9V/2A, the charging speed will be lower.
- Q2:** Does the wireless charger hold a charge when unplugged, like an AirPod charger?
A2: NO! The wireless charger doesn't contain an inside battery to store power.
- Q3:** How do I know whether my device can use it?
A3: Please read the compatible sheet before purchasing.
- Q4:** Can I use the wireless charger in another country while traveling?
A4: The package contains an 18W adapter that can be used on the 100-240V power source.

7

- Q5:** Will the wireless charger still charge with a protective case on the back?
A5: Please take off the cellphone or earbuds cases before charging.

- Q6:** Why would the charging speed for iPhone get slower when it reaches 80% of the power?
A6: Please check if the cellphone is in trickle charge status. Then, try the following to improve the charging speed:
Open [Settings] - [Battery] - [Battery Health] - [Turn off battery optimization].

Troubleshoot

1. When the phone or watch cannot be fully charged, try the following:
Open [Settings] - [Battery] - [BatteryHealth] - [Turn off battery optimization].
2. When the blue light flashes, indicating abnormal charging, please check whether peripheral are around.
3. When the wireless charger stops charging, please reassemble the product and try it again.

8

ANY OTHER QUESTIONS?

Please contact the product support team to get quick technical support.

Product Support

With us, you have **24 Hours** email customer service for troubleshooting. **18 Months** of Product Support, Free Replacement.

Your satisfaction is always our top priority. Please feel free to contact us through the following steps:

- 1). Log in to your Amazon account.
- 2). Open your purchased orders
- 3). Click the store name next to "Sold by:"
- 4). Click "Ask a question."

Email: hicober@outlook.com

5