


CT12



User Manual

Please review this manual thoroughly before operating your device. In order to avoid unnecessary injuries, please do not Disassemble this product by yourself, and please use a standard charger.

Product Contains



Earbuds x2



Charging Case x1



USB Charging Cable x1

Product Specification


Driver: 16.2mm
Support Profile: HFP / AVRCP / A2DP
Earbuds Charging Time: Up to 1.5 Hour
Charging case Charging Time: Up to 1.5 Hours
Working Voltage: 5V
Transmission Range: Up to 10m
Working Temperature: -30° - 70°

Power on /off

1)Earbuds will auto power on and connect when you open the charging case.



2)Earbuds will auto power off and disconnect when you close the charging case.



3)If charging case open but earbuds don't power on, please charging the charging case.

Bluetooth Pairing



Setp1: Please turn on the Bluetooth function on your cellphone/laptop.
Step2: Open the charging case, the redand white lights flash on earbud.
Step3: Select "CT12" on your phone/laptop and connect the device, the white lights on 2 second and off when you connect successfully.
(The earbuds will automatically turn off if not connected the device within 5 minutes.)

Reset Earbuds

If only one earbud connects to phone / earbuds can not pair together. Please try the reset steps:


Step 1: Open the charging case and check the charging cases.
Step 2: Keep the earbuds in the charging case and long press the reset button about 10S.

Step 3: When the earbuds alternately flash red and white lights. It means the reset is successful.




Reset

Product Wear



Step1: Take out the earbuds from charging case.
Step2: Put the earbuds on your ears.
Step3: Adjust by twisting the earbuds for comfort and secure.

MFB Button Control



- Answer a call**
Click either earbuds button
- End a call**
Click either earbuds button once
- Reject call**
Long press either earbuds button for 2 seconds
- Voice Assistant**
Triple click either earbuds button to call voice assistant
- Volume Up**
Long press right earbud button
- Volume Down**
Long press left earbud button
- Play/Pause**
Click either earbuds button once
- Previous Song**
Double click left earbud button
- Next Song**
Double click right earbud button

Product Charging

1)Put the earbuds back charging case to charging earbuds.



2)Plug in the USB type-C to charge the charging case, the white light of the charging case will flash.



Power Display of Case and earbuds



3)When your earbuds and charging case is full power, the charging case's light will off.

Certification

"This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation."

FCC ID: 2A7GB-CT12

Safety For You

- Do not expose device to liquids, moisture or humidity. It has electronics and a battery in it. Neither of them likes getting wet.
- Don't use abrasive cleaning solvents to clean your device. Wipe them down with a slightly damp cloth if and when necessary.
- Remove and clean the earbuds tips regularly, to ensure that you always enjoy the best sound possible from your device.
- Do not expose device to extremely high or low temperatures as this may damage the battery or even deform the plastic parts.
- Don't throw yours device in a fire to dispose it. The internal battery may explode.
- Don't try to disassemble your device. There are no user serviceable parts inside it.
- Try not to drop your device and keep it away from sharp objects such as keys in your pockets.
- Only charge your device from 5V USB ports such as phone chargers and laptops or PCs.
- Never listen to music at high volumes or you may permanently damage your hearing.
- Pay attention to your surroundings and never wear any headphones while riding, driving or walking in traffic. You do not come with any warranty.