User Manual for Remote LED Candles

Introduction:

Thank you for purchasing our remote LED candles. This user manual will guide you through the various functions and important considerations to ensure a safe and convenient experience. Please read the following instructions carefully.

Remote Control Functions:



Power On/Off: Use the remote control to easily turn the candles on and off.
Timer Function: Select the desired timer mode (2H/4H/6H/8H) to automatically light up the candles for the specified duration and turn them off for the remaining time in a 24-hour cycle. This feature eliminates the need to manually turn the candles on and off every day.
Lighting Modes: Choose between Always On Mode for a steady glow or Flickering Mode to create a flickering effect similar to real candles.
Brightness Adjustment: Adjust the brightness of the candles according to your preference.
Remote Range: The remote control has a range of 0-16 feet (0-5 meters), allowing you to operate the candles from a convenient distance.

Important Tips:

3.1 Battery Activation: Before using the remote control, please remove the transparent sheet to activate the batteries.
3.2 Outdoor Use: The candles are not waterproof. To avoid damage from rain, always place the candles in a lantern or mason jar when using them outdoors.

Child Safety

For safety reasons, please ensure that children do not have access to the batteries. This will prevent any potential danger of swallowing the batteries.

⚠ WARNING

THIS PRODUCT CONTAINS A BUTTON BATTERY

If swallowed, a lithium button battery can cause severe or fatal injuries within 2 hours.

Keep batteries out of reach of children.

If you think batteries may have been swallowed or placed inside any part of the body, seek immediate medical attention.