




BIOS settings will reset back to default if the customer updated the BIOS.

**Solution:** Change the SATA Operation mode to **Intel RST PREMIUM (RAID)** from AHCI.



Press F6 to save configuration.



Fixed.