

3D Led Candle User Manual

Package Contains:

Led Candles
1xRemote Control
1xUser Manual

BATTERY INSTALLATION:

Do not mix Alkaline, Standard (Carbon-Zinc) or Rechargeable (Nickel Cadmium/Nickel Metal Hydride) batteries and install only new batteries of the same type in your candle. For prolonged candle life, use **alkaline batteries**.

1. Your candle requires two (2) C batteries (sold separately)
2. Turn candle over and remove cover from battery compartment.
3. Insert two C batteries as illustrated in the battery compartment.
4. Replace battery compartment cover.

Kindly noted:

Please make sure the battery direction is correct when insert batteries



OPERATION

ON/OFF

To turn candle on, slide power switch on bottom of candle to "4/8 hour" position.

To turn candle off, slide power switch on bottom of candle to "OFF" position.

TIMER

To set timer, slide the power switch to the "4 / 8 TIMER" position. Candle will remain on for 4 hours from the time you place the candle in "4 / 8 TIMER" mode, and then automatically turn off for 20 / 16 hours. It will repeat the same cycle daily.

To reset timer, slide power switch to "OFF" position and then to "4 / 8 TIMER" at the desired start time.

Remote Control

The effective distance of the remote control is 3M

Your candle has an 4 Hr/OFF/8 Hr switch, but can be set to either a 2, 4, 6 or 8 hour timer with the remote control.

To use the remote, turn the power switch to either the 4 or 8 hr positions on the candle

1. Remove the Battery insulation sheet in the back of remote
2. When the candle is ON, press 2H, 4H, 6H or 8H to set the candle "burning" time
3. Once the timer is set, the flickering candle will be ON for 2, 4, 6 or 8 hours and will remain OFF for 22, 20, 18, or 16 hours, turning back ON automatically at the same time the following day.
4. To adjust the mode of candle light, press "Candle" to get flickering light or "Light" to get steady light.
5. To adjust the brightness of the candle use the two dimmer buttons to adjust for brighter or dimmer candle light
6. To turn off the candle light, press "OFF"



WARNING

To prevent your batteries from leaking, take them out if you plan on not using your device for longer periods of time.

Your flameless candle should not be exposed to extreme heat, cold or water and is intended for indoor use only. The flickering candle is made of real wax, and if exposed to high heat, will soften and/or melt and deform the shape of the candle.