

OPERATION OF THE TEMPERATURE SETTINGS ON A EA8250



EA8250



Fil water tank



Place on the EA8250



Turn on the EA8250



EA8250 turned on.



The first screens are setup screens (language, time, date water hardness, etc.
Do the setup



Press OK to fill the EA8250



Should always press yes to clean out the heating element



Coffee setting display
Different types of coffee that can be made.



At coffee setting display you can press the prog button.



Go to settings



Go to coffee temperature.



Here you can adjust the temperature. One being the lowest and three the highest.



Fill the bean hopper.



Went to coffee on the coffee display screen.



Made 4oz of coffee on all three temperature settings



Temperature setting number one



Temperature setting number two.



Temperature setting number three.