



Manufacturer:

Shenzhen Hanke Technology Co. Ltd

Address:

Meipeng SKY311, No.3 Hebei Industrial Zone, Zhongxing Road, Ma'antang Community,

Bantian Street, Longgang District, Shenzhen, Guangdong, China, 518000

E-mail:

support@bluedee-tech.com




Made in China




Model: BD-SK200
PC Gaming Sound Bar
User Guide

PACKAGE CONTENTS



①



②



③



④



⑤


- ① 1 x Power Adapter
- ② 1 x 3.5mm Audio Cable
- ③ 1 x User Guide
- ④ 1 x Sound Bar (Model: BD-SK200)
- ⑤ 1 x Wall mounting guide card

PRODUCT DIAGRAM



①

①



⑦


⑥

⑤

④

③

②



PRODUCT DIAGRAM

- | | |
|-------------------|-------------------|
| ① Speaker | ⑧ AUX Input port |
| ② Power Button | ⑨ AUX Output Port |
| ③ Volume + | ⑩ Power Port |
| ④ Volume - | ⑪ Mount Holes |
| ⑤ Play / Pause | ⑫ Rubber Feet |
| ⑥ Bass Button | |
| ⑦ LED Mode Button | |

Note:

The mounting screws are not provided.
please remove the protection from the rubber feet before use.

IMPORTANT SAFETY INSTRUCTIONS

Please read the instructions thoroughly before using this product and retain it for future reference.



Warning

- Never place the Sound Bar near the heat sources.
- Only use this Sound Bar indoors.
- Never place this Sound Bar on other electrical equipment.
- Keep the product clean and dry. Do not clean the product with detergent containing alcohol, ammonia, benzene or abrasives.



Caution

- Do not expose this product to high temperatures.
- Store this product in a dry place. Keep it away from humidity and corrosives.
- Do not immerse the Sound Bar into water or expose them to humidity for a long time.
- Avoid dropping.
- Close attention is needed when using near children.
- Unauthorized disassembly of any parts of this product is forbidden.
- Always ask a professional technician or authorized personnel for repair.



BUTTON CONTROL

Function	Operation	Voice Prompt
Power On / Off	Press and hold the Power Button for three seconds	Beep sounds
Mode Change (BT / LINE)	Press the Power Button when the speaker is on	'Bluetooth mode' 'Wired mode'
Play / Pause	Press the Play / Pause button	/
Go into Pairing Mode	Press and hold the Play / Pause button	'Pairing'
Successful Connection	/	'Connected'
Volume +	Press the Volume + button	Toots when highest setting is reached
Volume -	Press the Volume - button	/
Next Track	Press and hold the Volume + button under the Bluetooth mode	/

Previous Track	Press and hold the Volume - button under the Bluetooth mode	/
Switch to Bass Mode	Press the Bass button	/
Set the Light Mode	Press the LED Mode button to choose the following four light modes: ① Color carousel: where the light will cycle through different colors ② Breathing mode: where the light will cycle through different colors in a rhythm resembling human breathing ③ Rhythm mode: where the light color and brightness will change automatically with the music you are playing ④ Turn off the light	/
Answer / Hang up Phone Call	Press the Play / Pause button	/
Decline an Incoming Call	Press and hold the Play / Pause button	/

HOW TO USE


Place the unit




1. Place this unit on top of a table or mount it on the wall.

Note:

- The mounting screws are not provided.




2. Never place this unit in an enclosed cabinet when the sound bar is playing.




3. Install this unit near the AC outlet where the AC power plug can be easily reached.


Bluetooth Connection




1. Plug the sound bar to power, press and hold the Power Button for three seconds until the beep sounds are heard. The device is in the Bluetooth mode initially.



2. When the voice prompt 'Pairing' is heard, activate the Bluetooth function on your device and search for Bluetooth connections nearby.



3. Find " BD-SK200 " in the search results and tap to connect.




4. The voice prompt 'Connected' will be heard upon a successful connection.

Note:


- When it's power on, the sound bar will automatically connect to the device last paired if any. Otherwise, it will enter the pairing mode **again**.
- To change the connection, press and hold the Play / Pause button to enter the pairing mode and connect another device.

Bass Button


1. Press to switch between Bass mode and Balance mode.
2. Voice prompt will be heard upon the switch.

AUX Cable Connection

1. Plug in the AUX cable into the AUX input port at the back.



2. Press the power button to change to **AUX mode**, the voice prompt 'Wired mode' will be heard.



3. Connect to an AUX device via the cable.

Note:

- Once connected to the AUX Output port, the sound will be bypassed to the audio device connected.

CLEANING AND MAINTENANCE

1. Clean the Sound Bar on a regular basis.
2. Use dry and soft cotton cloth to wipe the unit.
3. Keep away from sharp objects to avoid scratches.
4. Put the unit in a dry and shady place if it is to be idle for a long time.
5. Do not clean the product with detergent or chemicals.

Note:

- Do not insert anything into the product.

WARRANTY AND SERVICE

If any problems occur, please contact the **Bluedee** Customer Care Centre via the contact information listed in this User Guide.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.