


Guide: Adjusting PIR Sensitivity Made Easy"

1. How to set the best working mode?

Step 1: Make sure your doorbell is online, the wifi signal is stable, and the battery is healthy

Step 2: Enter the device settings interface, click Power Manager, scroll down to the bottom of the interface, and select the corresponding working mode according to the different working mode descriptions and your actual scenario requirements.



2. How to set the best motion detection?

Step 1: Make sure your doorbell is online, the wifi signal is stable, and the battery is healthy

Step 2: Enter the device settings interface, click Motion Detection, scroll down to the bottom of the interface, select according to the Sensitivity option description and your actual scenario needs. If there are a few missed events, you can increase sensitivity by one bar. If there are a large number of missed events, it is recommended to adjust the sensitivity to the highest level.

