




User Instruction for Laptop Backpack



Dimension of the Laptop Backpack: 18 * 13 * 6 inch.

▲Note: 1-2cm error of measuring is a reasonable range due to different measurement methods.

Multifunctional Computer Backpack:


SAFETY FUNCTION

ANTI THEFT PASSWORD LOCK



- Anti-theft Combination Lock
- Double Zip Pocket

Night Light Reflective



- Night backpack with reflective straps

Anti-theft combination lock of Instructions:

(Follow steps 1 to 4 to set up, then remember the new password)

- ① Pull up the shackle to open the lock
- ② Rotate the shackle 90° counterclockwise and press all the way down, hold down
- ③ Set your own combination by using dials
- ④ Turn the shackle back as normal, then the setting is completed, to reset a new combination.

The original number is 0-0-0. To set your own combination, please follow these easy steps:

