



Website: www.xmarto.com
Support: support@xmarto.com




IP Camera User Guide

Content

1. How the camera works	1
2. Camera Tail	1
3. How to set up the camera	2
3.1 Install App and create App account	2
3.2 Plug camera to power	2
3.3 Add camera to App	3
4. App - Camera List	5
5. App - Live Footage	6
6. App - Video Playback	7
7. Camera Settings	8
8. Motion Detection Management	9
9. Record Schedule	9
10. PTZ Control	10
11. Presets	10
12. Camera Light Control	11
13. PTZ Speed Setting	11
14. Advanced Settings	12
15. Me - App Overall Settings	13



1. How the camera works



2. Camera Tail



3. How to set up the camera

● **Tips:** at xmarto.com we have videos to help you with setup.

3.1 Download **xmarto WallPixel** App. Spend a few minutes to register an user account and login.

You can scan below QR code to find the Apps.



xmartO WallPixel



Apple iOS



Android

3.2 Bring the camera close to your Wi-Fi router, plug it to power.





3.3 In App,tap + to add camera, select your camera type.



The camera can be setup with or without cable.



(A)



(B)



(A). Add via WiFi without cable

Choose **NO** while asked whether camera has Ethernet port. Then follow on-screen guide to setup camera.

(B). Add with cable

Use an Ethernet cable to hard wire the camera to your router's LAN port. Select **YES** while asked whether the camera has Ethernet port. Then follow on-screen guide to add the camera to list. The camera is then working wiredly.


Enter camera's setting - Advanced setting - Device WiFi. Provide your WiFi password and then you can unplug the camera from router.

If the camera was not added successfully, hold the reset button for 10 seconds and do it again. Make sure to provide **CORRECT WiFi hotspot and password (2.4G WiFi only)**.




4.App - Camera List

- ① Group. With group, you can group multiple cameras to a quad view or multiple view. Then you can view multiple cameras simultaneously with one tap.
- ② One key Switch - At Home/ Away Mode.
At home mode – owner is at home, camera DOES NOT RECORD
Away mode – owner is away, camera records.
- ③ Camera name, network status
- ④ Quick menu to recorded photos & videos,edit/ delete camera.
- ⑤ Share device with families or friends
- ⑥ Alarm messages
- ⑦ Video playback
- ⑧ Camera settings



5.App - Live Footage





6. App - Video Playback

In camera list, tap **Playback** to play camera's recorded videos.
Make sure you have **Micro SD card** in the camera.




1. Video backup/ camera settings shortcut.
2. Calendar: Choose date.
3. Snapshot. Save a snapshot to mobile.
4. Record. Record a video clip to mobile.
5. Video timeline: drag to change time, color bars are event videos.
6. Enlarge timeline for easy operation.



7. Camera Settings

In camera list, tap **Setting** to enter camera settings.



- ① Audio ON/ OFF
- ② Voice instruction – voice guide settings
- ③ Motion detection settings
- ④ Record schedule settings
- ⑤ Sync camera time with your mobile
- ⑥ Mode selection – detect & record plans while user is away/ at home.
At home mode – owner is at home, camera DOES NOT RECORD
Away mode – owner is away, camera records.
- ⑦ Firmware update for camera
- ⑧ Device micro SD card storage status
- ⑨ Advanced settings





8. Motion Detection Management



1. Motion recording ON/ OFF
2. Turn motion-triggered msg ON/ OFF
3. Adjust motion detection sensitivity
4. Turn ON/ OFF motion-triggered siren

9. Record Schedule



In Record Schedule, you can shedule record time for cameras.




10. PTZ Control



- Preset
- PTZ Speed
- Zoom Out
- Zoom In
- Adjust Direction
- Adjust Focal

11.Presets



Tap + to record preset points. Tap Go to view the point.



12. Camera Light Control



This works only for cameras with floodlight.


IR IR LEDs light up automatically at night. Night vision is in B/W.

Floodlight Floodlights stay up at night. Night vision is in color.

AUTO/ Smart (recommended): At night IR LEDs turn up for night vision; when motion detected, the camera turns on floodlight to deter intruders away and image turns color.



14. Advanced Settings




In advanced settings, you can set timezone, video image, Device username and password.

In Device WiFi, you can update the camera's WiFi connection.

● Important tips: please set your password to secure your camera.



13. PTZ Speed Setting



PTZ speed level 1-8



15. Me - APP Overall Settings



1. Tap profile photo to enter App account settings; includes email, phone number and change App login password.
2. Setting – App push alert ON/ OFF and other app settings.
3. Snapshot/ Record. Access photos & videos you saved to mobile.
4. Device share management. Manage device sharing.
5. Push notification. Turn App notificaton ON/ OFF.

Note: While using the product, please complain with your local laws and regulations of audio & video devices.

If you have further questions, please refer to help center at, www.xmarto.com

or contact us at support@xmarto.com

Thank you!

www.xmarto.com

support@xmarto.com