


49UN7300AUD
49UN7300PUC
49UN7300PUF

50UN7300AUD
50UN7300PUC
50UN7300PUF


55UN7300AUD
55UN7300PUC
55UN7310PUC
55UN7300PUF

60UN7300PUA
60UN7310PUA
65UN7300AUD
65UN7300PUC


65UN7310PUC
65UN7300PUF
70UN7370AUD
70UN7370PUC





1
49/50/55UN73*




2




3




1
60/65/70UN73*




2




3




1




2




3-A 49/50/55/60/65UN73*




3-B 70UN73*




4-A 49/50/55UN73*





4-B 60/65/70UN73*



5



6









www.lg.com/us/support


ENGLISH
Easy TV Connect Guide
(Animation)

ESPAÑOL
Guía Rápida de Conexión
del televisor
(Sólo en Inglés)

FRANÇAIS
Guide simplifié pour la connexion
du téléviseur (Offert
en anglais seulement)



A, B, C, D, E : mm (inches / pulgadas / po)
F, G : kg (lbs / libras / lb)



MODELS MODELOS MODÈLES	A		B		C		D		E		F		F-G		Power consumption Consumo de potencia Consommation électrique
	mm	(inches)	mm	(inches)	mm	(inches)	mm	(inches)	mm	(inches)	mm	(inches)	mm	(inches)	W
49UN7300PUF	1,110 (43.7)	1 110 (43.7)	705 (27.7)	705 (27.7)	235 (9.2)	235 (9.2)	650 (25.5)	650 (25.5)	81.1 (3.1)	81.1 (3.1)	11.3 (24.9)	11.3 (24.9)	11.1 (24.4)	11.1 (24.4)	120 W
49UN7300AUD 49UN7300PUC	1,110 (43.7)	1 110 (43.7)	709 (27.9)	709 (27.9)	231 (9.0)	231 (9.0)	650 (25.5)	650 (25.5)	81.1 (3.1)	81.1 (3.1)	11.3 (24.9)	11.3 (24.9)	11.1 (24.4)	11.1 (24.4)	120 W
50UN7300PUF	1,130 (44.4)	1 130 (44.4)	719 (28.3)	719 (28.3)	235 (9.2)	235 (9.2)	663 (26.1)	663 (26.1)	86.3 (3.3)	86.3 (3.3)	11.4 (25.1)	11.4 (25.1)	11.3 (24.9)	11.3 (24.9)	140 W
50UN7300AUD 50UN7300PUC	1,130 (44.4)	1 130 (44.4)	722 (28.4)	722 (28.4)	231 (9.0)	231 (9.0)	663 (26.1)	663 (26.1)	86.3 (3.3)	86.3 (3.3)	11.5 (25.3)	11.5 (25.3)	11.3 (24.9)	11.3 (24.9)	140 W
55UN7300PUF	1,244 (48.9)	1 244 (48.9)	783 (30.8)	783 (30.8)	235 (9.2)	235 (9.2)	726 (28.5)	726 (28.5)	87.1 (3.4)	87.1 (3.4)	14.4 (31.7)	14.4 (31.7)	14.3 (31.5)	14.3 (31.5)	160 W
55UN7300AUD 55UN7300PUC	1,244 (48.9)	1 244 (48.9)	786 (30.9)	786 (30.9)	231 (9.0)	231 (9.0)	726 (28.5)	726 (28.5)	87.1 (3.4)	87.1 (3.4)	14.5 (31.9)	14.5 (31.9)	14.3 (31.5)	14.3 (31.5)	160 W
60UN7300PUA 60UN7310PUC	1,368 (53.8)	1 368 (53.8)	857 (33.7)	857 (33.7)	255 (10.0)	255 (10.0)	796 (31.3)	796 (31.3)	89.1 (3.5)	89.1 (3.5)	19.6 (43.2)	19.6 (43.2)	19.4 (42.7)	19.4 (42.7)	175 W
65UN7300PUF	1,463 (57.5)	1 463 (57.5)	910 (35.8)	910 (35.8)	255 (10.0)	255 (10.0)	850 (33.4)	850 (33.4)	87.8 (3.4)	87.8 (3.4)	21.5 (47.3)	21.5 (47.3)	21.3 (46.9)	21.3 (46.9)	195 W
65UN7300AUD 65UN7300PUC 65UN7310PUC	1,463 (57.5)	1 463 (57.5)	914 (35.9)	914 (35.9)	269 (10.5)	269 (10.5)	850 (33.4)	850 (33.4)	87.8 (3.4)	87.8 (3.4)	21.6 (47.6)	21.6 (47.6)	21.3 (46.9)	21.3 (46.9)	195 W
70UN7370AUD 70UN7370PUC	1,578 (62.1)	1 578 (62.1)	984 (38.7)	984 (38.7)	299 (11.7)	299 (11.7)	913 (35.9)	913 (35.9)	91.1 (3.5)	91.1 (3.5)	31.4 (69.2)	31.4 (69.2)	30.7 (67.6)	30.7 (67.6)	225 W

Power requirement / Alimentación requerida / Alimentation

AC 120 V - 50 / 60 Hz



ENGLISH Read **Safety and Reference**.
ESPAÑOL Leer **Seguridad y Consultas**.
FRANÇAIS Lisez **Sécurité et références**.

ENGLISH
Easy Setup Guide
Please read this manual carefully before operating your set and retain it for future reference.

ESPAÑOL
Guía Rápida de Configuración
Lea atentamente este manual antes de poner en marcha el equipo y consérvelo para futuras consultas.

FRANÇAIS
Guide de configuration rapide
Avant d'utiliser l'appareil, veuillez lire attentivement ce manuel et le conserver pour pouvoir vous y reporter ultérieurement.

⊕ : Depending upon model / Según el modelo / Selon le modèle