



SNK 40<sup>th</sup>  
Anniversary



# NEOGEO mini

PRO-GEAR SPEC  
ADVANCED ENTERTAINMENT SYSTEM

## INSTRUCTIONS



## Introduction

Thank you very much for purchasing 'NEOGEO mini'.  
Please carefully read the INSTRUCTIONS before use, and use the product in the correct manner.  
Please store the INSTRUCTIONS properly.

## Health precautions



### Warning

To avoid of causing damage to health, please make sure you pay attention to the following items.

- Do not sit too close to the screen when using the product. Do not use the product in a dark place. The light from the screen can cause excessive irritation to the eyes. When a user is watching the screen, he or she may experience temporary vertigo or muscle spasms or even lose consciousness under the stimulation of strong light or rays, depending on the individuals' physical condition and physique. If you experience any of the above stated symptoms, stop using the product immediately and promptly see a doctor. If you have encountered any of such symptoms before, please consult your doctor before using the product.
- Do not continuously use the product for a long time. For the safety of your health, make sure to rest every 10 to 15 minutes per hour of gameplay.
- Do not use the product when you are tired. This may lead to adverse effects on your health.
- If your hand or arm is injured or if you feel any sort of pain, consult your doctor before using the product. If you play the game while your hand or arm is injured or if you are feeling any sort of pain, it may cause the symptoms to worsen.
- If you suffer from dizziness or headache, nausea, motion sickness or any sort of pain in your eyes, hands, arms, etc. or feel tired or unwell, stop using the product immediately. If these symptoms persist, please promptly go to see a doctor.

## Safety precautions for use



**Warning** To avoid of causing fires, electric shocks or injuries, please make sure you pay attention to the following items.

- Do not use, install or store the product in the following places.
  - Places your children can easily reach
  - Unstable places
  - Dusty or excessively damp places
  - Places that receive direct sunlight or high temperature or near high-temperature objects
- Do not get the console or wires wet, or place them in any liquid or foreign matter. If any liquid or foreign matter penetrates into the console or the wires, stop using them immediately.
- Do not apply any strong shocks or excessive force to the console or wires. Do not heat the console or wires.
- Do not disassemble or modify the console or wires. If the console or wires are damaged or deformed, stop using them immediately and do not try to repair them by yourself.
- Do not allow the port to come in contact with any metal.
- Regularly clean the port or plug with a dry cloth or swab to prevent them from becoming dirty due to dust.



**Caution** To avoid of causing damage, malfunction or exhibit improper operations, please make sure you pay attention to the following items.


- Do not scratch or press hard on the surface of the LCD screen.
- Do not place the LCD screen in direct sunlight for a prolonged amount of time, when using the product near a window, avoid direct sunlight on the LCD screen.
- Do not press hard on the LCD screen and its surrounding areas. Due to the weak bearing ability of the LCD screen, if excessive force is applied to it, it may cause malfunction.
- Do not connect the product with devices that are incompatible with the product.
- Do not disconnect the USB cable when the console is turned on.
- Do not use thinners, gasoline, alcohol or any other solvents to clean the product.
- Do not use or place the console in places where temperature suddenly changes, in order to avoid misting the display.
- Please dispose the product when it's no longer useful according to the instructions of the local government.

## How to operate

### Warning

When inserting/pulling out a connector, please make sure you hold the connector with your hand and insert and pull it out directly without exerting any excessive force. Also, please make sure you check the direction of the port and insert the plug into it correctly.

※ When supplying power from a power outlet, please use a commercially available USB-compatible DC adapter. It is recommended and suitable to use an DC adapter that can output 5 V / 1.0 A / 5 W.



Please plug Type-C connector carrying a power supply USB cable into the dedicated port on the back of NEOGEO mini console (Figure ①), and connect the connector on the other end of the USB cable to the USB port of TV or PC (※). In addition, you can use any other proper available USB-compatible DC adapter to supply power from the power outlet. After the connection completes, press the power switch on the back of the console (Figure ②) to start NEOGEO mini.  
※For some consoles, you must press the power switch to charge them before they can be started.

### ■ How to connect TV to play

Insert the HDMI cable into the HDMI output port (Figure ③) on the back of the console and the HDMI input port of the TV.


### ■ How to use headphone or speaker

The headphone port of this console supports 3.5mm standard plug. If you need to connect the headphone or speaker, please connect through the headphone port on the back of the console (Figure ④).


### ■ How to use NEOGEO mini PAD

Insert NEOGEO mini PAD connector into the PAD port on the side of the console to connect it (Figure ⑤).

## HOW TO CHANGE DEFAULT LANGUAGE



STEP ONE:  
SELECT Settings Icon



STEP TWO:  
SELECT Language