


User Manual

Wearable Vibrator (App Control & Remote Control)



Please fully charge before use for the first time
Read the manual carefully before using the product please!

RoHS
Made in China

CE


△
7
OTHER

△
20
PAP




MADE IN CHINA

Product View



Top Vibrating Mode
Head Vibrating Mode
Switch/Tail Vibrating Mode



Product Specification

Product Name: Wearable Vibrator(App Control & Remote Control)

Material: ABS & Food Grade Silicone

Product Size: 1.9 * 6.0 * 4.7 inches/1.5 * 2.4 * 0.6 inches

Waterproofing Grade: IPX6

Accessories: USB Charging Cable

Battery Capacity: 500mAh

Rated Voltage: 3.7V

Power Supply: Built-in Lithium Battery

Noise: ≤45db

Charging Time: 2 h

Using Time: ≥50mins

Attentions

1. Please check if there is any damage caused by transportation, if for sure, please contact the seller for replacement.
2. Please read and follow the user manual before using.
3. This product is for adults use only, can NOT be used as a contraceptive.
4. Please put the product in proper condition and out of the reach of the children.
5. Please do NOT exert excessive force when using to avoid injury.
6. Please do NOT share the product with others.
7. Please immediately stop if you feel any uncomfortable when using this product.
8. Please check the condition of the product regularly, please stop using if any damage is found.

How to Use & Button Description

Wearable Vibrator

	After power on, press  button to enter Top Vibrating Mode. Enter next mode by pressing the button again, there are 3 speed modes & 3 frequency modes available.
	After power on, press  button to enter Head Vibrating Mode. Enter next mode by pressing the button again, there are 3 speed modes & 3 frequency modes available.
	Switch on/off by pressing 2 seconds. After power on, press  button to enter Tail Vibrating Mode. Enter next mode by pressing the button again, there are 3 speed modes & 3 frequency modes available.

Remote

	After power on, press  button to enter Top Vibrating Mode. Enter next mode by pressing the button again, there are 3 speed modes & 3 frequency modes available.
	After power on, press  button to enter Head Vibrating Mode. Enter next mode by pressing the button again, there are 3 speed modes & 3 frequency modes available.

Continued



Switch on/off by pressing 2 seconds.

After power on, press button to enter Tail Vibrating Mode. Enter next mode by pressing the button again, there are 3 speed modes & 3 frequency modes available.

How to Charge(LED Indicator)

Power on	Indicator on.	
Working	Indicator flashes when pressing button.	
Power off	Indicator off.	
State of charging	Low power	Indicator flashes slowly for 5 times and the vibrator off automatically.
	Charging	Flashing.
	Fully Charged	Indicator on.

Recycling Guide

The raw materials of this product are in line with environmental requirements. The product has a built-in lithium battery, so it can not be thrown away anywhere when you are not using it anymore. Please return the products with lithium batteries to the professional recycling site, and then by a unified treatment. Pay attention to protect the environment.

How to Install

This product does not need to be installed. But please fully charge before use for the first time.

Remote control can be used directly without any installation operation.

The APP installation method is as follows.

Download and install " Love Spouse "



Love Spouse APP



Scan the QR code to activate and extend your warranty

IOS system:

1. Search for " Love Spouse "  in App Store, download and install.
2. Scan the QR code with your mobile phone, and follow the prompts to download and install the " Love Spouse " APP.

Android system:

1. Search for "Love Spouse"  in Google Play, download and install.
2. Scan the QR code with your mobile phone, select the first or third one, and follow the prompts to download and install the " Love Spouse " APP.

Register and log in



Love Spouse

account

please input your email

password

to input your password

[forget password](#)

[log in](#)

[new user registration](#)

[sign in](#)

enjoy everyday

By logging in, you agree to our

[Terms & Conditions](#) and agree to [Privacy Policy](#).


1. Click the "Love Spouse" icon to enter the APP, please register for the first login.
2. Click "New User Registration" and complete the registration with your mobile phone number or email address. When the mobile phone cannot receive the verification code, please use the email to register instead.
3. After registration, enter the account and password to log in to the App.

Device Binding

1. Before binding, please enable Bluetooth function of mobile phone.
2. Open your "Love Spouse" App, tap "+" on home interface of App, scan the Identification Code below to bind the device.(View1&2)



View 1




View 2

3. You can also enter the device code “7711” to bind the device.(View3)

4. After binding successfully, long press the device, name/image to rename or delete device if necessary. After the device is deleted, if you want to restore it, you need to scan the device binding code or enter the code number again.(View4)



View 3




View 4

Device Connection




View 5




View 6

1. First turn on the switch of the device, and then click the device icon in the APP. If the Bluetooth of the mobile phone is not turned on at this time, a prompt to allow Bluetooth to be turned on will appear. (View 5)
2. After clicking Allow, the mobile phone will automatically turn on the Bluetooth (iPhone Manually turn on the Bluetooth switch). At this time, the device and the phone begin to establish a connection, and enter the device control interface after the connection is successful. (View 6)

Equipment connection




View 7



View 8

1. Classic mode: Click any icon in 3*6 mode on the APP, and the device will start the corresponding vibrating frequency. At the same time, the icon on the APP will flash. Click this icon again, the device will stop vibrating and enter the standby state, and the APP icon will also stop flashing. (View 7)

2. Video mode: Click on the video mode or slide the operation interface of the APP to enter the video mode. You can click the "select local video" to choose any one you like, then you can enjoy those 3*6 modes with your own video part. (View 8)



listening to music...

*Please return to this page after playing music
on your phone*

*Otherwise, you will not be able to control the
device according to the rhythm of the music*



View 9

3. Music mode: Click on the music mode or slide the operation interface of the APP to enter the music mode. The APP will automatically search for the music player in the mobile phone. If you click on a music player to play music, the device will vibrate as the music changes. If you want to stop the music mode, click or slide to other control interface. **(View 9)**


NOTE: If the sound of the mobile phone playing music is too low, it may not be able to drive the device to vibrate. Apple phones can only use the music player that comes with the system.

4. Draw something: Click on the draw something or slide the operation interface of the APP to enter the draw something. and the **(View 10)** interface appears, draw a line at will on the screen. As you draw the line, our vibration mode is activated. When you stop drawing the line, the vibration stops.

View 10



View 11



View 12

5. Game mode: The game is a composite mode, two of the same fruit can synthesize a larger fruit, synthesis connected to the device in the state of power will generate vibration, with your superb game technology to synthesize more and larger fruits to occupy the leaderboard. **(View 11)**

6. Shake mode: Click on the shake mode or slide the operation interface of the APP to enter the shake mode, and the device will vibrate according to the shaking rhythm and amplitude of your phone. **(View 12)**



View 13



View 14

7. Interactive mode:

7.1 Tap the interactive mode or slide the operation interface of the APP to enter the interactive mode. Or just click the My device on the APP homepage to enter the interactive mode. **(View 13)**

7.2 Add friend

7.2.1 Click "+" to show the interactive interface, and you will enter the page **(View 14)**, you can search friend by his personal ID or email.

Personal information

Profile image



>

Nickname

Lua >

ID

3572591846

Birth date


1995-01-01 >



[View 15](#)

[View 16](#)

7.2.2 After the search results are displayed, click the add button on the right, and the system will send the friend request information to the target user. (**View 15&16**)




View 17

View 18

7.2.3 After the other party receives the message of the friend application, click the message button to enter the message center to View the message (the red dot is the unread message)(View 17), agree or reject the other party's friend application.


7.2.4 After the friend is successfully added(View 18), click the friend icon to send message, delete, black out, or report the friend.




[View 19](#)

7.2.5 Go back to the homepage and click my device to in the interactive mode, and select your friend which you want to interacted.(**View 19 & 20**)

7.2.6 After the interactive connection is successful, the video is not turned on by default. You need to send invitation of video or voice(**View 21**) and the other party agrees to open the video function before opening both parties.(**View 22**)



[View 20](#)



NOTE:

1. If the other party is not connected to the toy, your interactive interface has no control buttons at this time. The toy must be connected to the other party to have control buttons on your interactive interface. The device connection button on this interface is the Bluetooth icon in the upper right corner.
2. When interacting, the control button is to control the other party's device, not your own device.

FCC Caution

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.