

SPECIAL PRECAUTIONS

WHO CAN USE THIS LEASH?

- Anyone who uses this retractable leash must read all of the instructions and warnings before use. Please read all information on all sides of this document before use.
- This retractable leash is more complex than traditional non-retractable leashes, and Wigzi®, LLC has published this information to protect people and dogs from injury and misuse.
- Only use this leash with dogs that do not exceed the weight limit listed on the leash packaging.
 - Always follow the directions listed in this booklet.
- Be sure to use your Dual Doggie Retractable Leash as intended, and never attach anything to the leash casing or leash at any time.
 - Never exceed two dogs on one Dual Doggie lead at any time.
 - The Dual Doggie Retractable leash

should not be used with only one dog, as the cord not in use may cause injury.

- Do not allow use with small children.
- Any minor who uses this leash must first be sure they can control their dog and have read all Special Precautions and Directions.

IS THIS LEASH RIGHT FOR YOU AND YOUR DOG?

Be sure to use your Wigzi® Dual Doggie Retractable Leash as intended. The Wigzi® Dual Doggie Retractable Leash is intended for use with two dogs. Never exceed two dogs on one Dual Doggie leash at any time. Do not use this leash with only one dog as the unused cord could cause injury. Never use more than one Wigzi® Dual Doggie Retractable Leash at a time. Do not exceed the weight limit of each line indicated on the leash packaging. Never attach anything to the leash casing or leash cord at any time.

Do not allow small children to use the leash. Users under 18 must be able to control the dog and have read all Special Precautions and Instructions prior to use. It is recommended children be supervised by an adult while walking with this leash. Do not use this leash with a disobedient or uncontrollable dog, as they are more likely to wrap the leash around people or to run off at high speeds.

Note: Pay attention to your dogs at all times. Dogs can still pull on the leash even after the handler has stopped the leash with the brake lock. Even small dogs can pull hard enough to injure you, as the length of the leash allows dogs to run and build up speed. If your dog is at a full sprint and comes to the end of the line, the jerk on your leash can cause you to fall or hurt your arm. **booklet for future reference.**


CONSIDER YOUR ROUTE AND DESTINATION

The Wigzi® Dual Doggie Retractable Leash is designed to give your dogs

more freedom while on a leash. You can use the retractable leash anywhere you would normally go with your dogs, but it is important to consider your surroundings. For example, if you go to the vet, groomer or any other crowded place, your dogs must be fully under your control and the leash must be fully retracted and the brakes locked. (Please refer to the section “Injury to Bystanders”). You may want to consider using a Wigzi® Standard Non- Retractable Dual Doggie leash in these and similar circumstances. Follow the “Directions” section in this pamphlet. Never attach more than one dog to each leash lead.

CUTS AND BURNS

Avoid contact with the Wigzi® Dual Doggie Retractable Leash and never let it wrap around any part of your body. If the leash cord touches across your skin, it can cause abrasions (like a rope burn) or severe cuts. Cuts and burns are more likely if the leash cord wraps around any part of the body.



Never let the leash wrap around any part of your body.

USE THIS LEASH ONLY AS INTENDED

Do not allow slack to build up in the leash - you or a bystander could get tangled in the slack and risk injury. Do not touch the leash cord if it wraps around you. To disentangle yourself, turn around until the leash cord is free from your body, or pass the handle from one hand to the other to unwrap yourself. (Refer to the section “Finger Amputation and Fractures”) Wear gloves, long sleeves and pants to protect your fingers, arms and legs, and to further reduce the risk of cuts and burns.


FINGER AMPUTATION AND FRACTURES

Do not touch the leash cord. Contact with the leash cord can cause injury, including finger fractures and amputation. Never let the leash cord wrap around fingers or hands; even a small dog can yank hard enough on the leash to amputate fingers and/or break bones. Never let the leash cord wrap around any rings or other jewelry worn on hands and wrists, as the leash cord may wrap around these objects and cause fractures and/or amputations. Never hold the leash cord for any reason; if the leash cord gets caught on shrubbery or other objects, make sure the dog is fully under control before untying.



EYE AND FACE INJURIES

Before attaching the Wigzi® Dual Doggie Retractable Leash to your dogs’ collars, inspect both the leash and the collars to make sure they are in good condition. If the leash or dog collar break during use, the leash cord can recoil back strongly enough to cause damage to the face and eyes; this can occur even with the lock engaged if the leash is under enough tension. A broken leash cord or collar can result in broken teeth, eye damage, cuts, abrasions, and bruises.




Example of collar breaking

Example of collar breaking and leash recoiling

FALLS

• The Dual Doggie is a retractable leash which will give your dogs more room to run freely. This also allows your dog to gain speed, enabling the dog to pull you harder, which could result in falling to the ground.

- Watch your dogs at all times. If your dog is at a full sprint and comes to the end of the line, the jerk on your leash can cause you to fall or hurt your arm.




Do not use the Wigzi® Dual Doggie Retractable Leash while riding a bicycle, using roller blades, or operating any type of transportation or machinery. The leash is intended for use only while walking or running.

SPECIAL PRECAUTIONS AND DIRECTIONS

Wigzi®, LLC wants you to have a fun and safe walk with your dogs. Before use, it is very important to read all instructions and warnings on both sides of this document.

This retractable leash is more complex than traditional non-retractable leashes, and Wigzi®, LLC has published this information to protect people and dogs from injury resulting from misuse. Always follow all instructions listed in this booklet. Wigzi®, LLC is not responsible for injuries resulting from misuse. Please keep this booklet for future reference.

INJURIES TO BYSTANDERS



Other people and other animals, can also suffer from all the potential injuries listed in this pamphlet, including tripping and being burnt or cut by the leash cord if it comes into contact with bystanders, or if it wraps around any part of a bystander's body.

Always be on the lookout for bystanders, who may not be aware of the leash. Be sure your dogs are under your control at all times. When around bystanders, make sure the leash cord is short enough to keep your dogs by your side

and in control with the brake locks engaged. Do not use this leash around small children, even those in strollers. In the event either leash cord comes into contact with a bystander, or wraps around a bystander, tell the bystander not to touch the cord; control your dog and do not touch the leash cord if the dog can still exert tension in the cord.

DIRECTIONS


INSPECT LEASH AND COLLAR BEFORE USE

Before each use, thoroughly inspect both your dog's collar and the Wigzi® Dual Doggie Retractable Leash to ensure that all parts are in working order and not damaged in any way. Attach the hook of the leash to the D-ring of your dog's collar only. Never attach it

to your dog's ID tag ring. At the beginning of each walk, make sure that each leash hook is fully closed and securely attached to the collar D-ring of each dog.



ATTACHING THE LEASH



Attach the hook of the leash to the D-ring of your dog's collar. Never attach it to your dog's ID tag ring. That ring is not strong and will break.

Make sure that the hook is fully closed and securely attached to the collar D-ring. Do this for each dog at the beginning of each walk.

DISCONNECTING THE LEASH

Make sure your leash is fully retracted and your dogs are under control before you detach the leads.

BEFORE USE

Before each use, thoroughly inspect your Dual Doggie and your pet's collar to ensure that all parts are in working order and not damaged in any way. Read all Dual Doggie instructions and warnings and refer to diagrams.

USING THE LEASH

1. Hold your Wigzi®Dual Doggie Retractable Leash by the handle on the casing; never hold the leash cord.
2. To stop both your dogs immediately, push both brake locks on the top of the leash casing down completely.
3. To lock just one leash cord, look to see the color of the dog's leash, which will correspond to one

of the buttons on the top of the leash case. Press fully down on the button that matches the color of the leash. You now have one dog locked while the other dog has free range. The leash will still spin to prevent entanglement while locked.

4. To unlock either brake lock, press down on the forward most button of the corresponding color. The brake lock will release.

6. To reel either dog in closer to you, move your arm toward your dog and push the brake lock button down to stop the reel; pull the dog closer to you with care. At this time, release the lock, and repeat until your dog or both dogs are at the desired distance.

7. To remove the Dual Doggie retractable leash from either dog, have the dog under control and the leash cord fully retracted inside the casing; the leash can now be safely removed.

CLEANING AND STORING YOUR DUAL DOGGIE LEASH

Use a damp cloth to clean the leash case only. Do not get the leash cord wet. Store your leash out of the reach of children and pets. We want you to have a long lasting leash and maintain the safety of pets and people.

WHAT TO DO IF THE CORD GETS WET

If the leash cord gets wet, extend the cord to its full length and use the lock button to keep the cord outside the casing. Dry the cord in a safe place where it will not come into contact with children or pets for 24 hours. When the cord is fully dry, secure the metal hook and slowly retract the tape back inside the casing, as the fully extended leash cord could snap back quickly and cause injury.

LIMITED WARRANTY

This Wigzi® Dual Doggie Retractable Leash is warranted to the original owner against manufacturing defects in materials and workmanship for the lifetime of the product. Wigzi® Dual Doggie Retractable Leash products are covered by a one year warranty that protects the original owner against manufacturing defects in materials. Warranty is effective from the date of purchase on your receipt. Please keep your receipt to use the warranty. If the Wigzi® Dual Doggie Retractable Leash fails due to a manufacturing defect, we will repair or replace the product without charge, to be determined at our discretion. Only original, unaltered, and unmodified materials and workmanship are covered by this policy. This warranty does not cover damage caused by accident, improper care, negligence, normal wear and tear, or the natural breakdown of colors and materials over extended time and use. **Leashes that have been chewed void the warranty.** Damage not covered under warranty may be repaired for a reasonable rate and a fee will be charged for return shipping.

WIGZI®, LLC
1655 N Fort Myer Dr #700
Arlington, VA 22209
info@wigzi.com
1-888-MY-WIGZI

Visit
www.wigzi.com
for more great products!



dual
DOGGIE™