



QUICK GUIDE

Mega

OPERATING INSTRUCTIONS




1 Lift the lid into a 90° position



2 Load the clothes inside the spin dryer. Insert the protector disk on top of the clothes, and inside the inner tub.




3 Close the lid completely




4 Turn the dial to the desired time (maximum time setting 5 minutes)

Note: Turn the dial starting from the "spin" position.

WARNING: Will not spin with lid open.
The security system does not allow opening the lid during operation.



Do not turn the dial beyond the "spin" position unless the lid is fully closed (Step 1)




Turn the dial to the position "OFF" and wait 30 seconds

closed.


AUTOMATIC TIMER RETURN TO THE OFF POSITION

5 After selecting the desired spin time will begin the process of centrifugation and the dial will automatically return to the position "OFF". Then the lid will be allowed to access the basket.



MANUAL TIMER RETURN TO THE OFF POSITION

6 If you wish to stop the machine before the cycle is over, manually turn the dial to the "OFF" position. Then wait 30 seconds for the lid to release.



WARNING: After the cycle is over, you must wait 30 seconds before opening the lid. Opening the lid before this can damage the machine.